

## **FIGURE 7897 & 7899 INSULATION COUPLINGS**

### **INTRODUCTION**

This instruction manual includes installation and proper use information for FNW figure 7897 and 7899 insulation couplings.

### **PROPER USE**

To avoid personal injury to yourself, fellow workers, or damage to property from improper use:

- a. Coupling spacing should be no more than 60 diameters.
- b. Keep conductor runs as straight as possible.
- c. Overwrap of coupling with insulation is not required.
- d. Figure numbers 7897 and 7899 are acceptable for horizontal or vertical installations.

