

Accessories and Replacement Parts

Accessories

MODEL NUMBER	DESCRIPTION
EX0061-0.3-AER	0.35 GPM Aerator (Male 15/16"-27, Female 55/64"-27)
EX0061-0.5-AER	0.5 GPM Aerator (Male 15/16"-27, Female 55/64"-27)
EX0061-1.0-AER	1.0 GPM Aerator (Male 15/16"-27, Female 55/64"-27)
EX145	Element Removal Tool – Series 6 and Series 12 only

Eemax Inline Flow Regulator

MODEL NUMBER	DESCRIPTION
IFR 1-2	1.0-2.0 GPM Flow Regulators with 1/2" NPT Fitting. <i>See page 14 or 28 for details</i>
IFR 3-4	2.0-5.0 GPM Flow Regulators with 3/4" NPT Fitting. <i>See page 14 or 28 for details</i>
EX0061-2.5-IFR	2.5 GPM with Flow Regulator with 3/4" NPT Fitting
EX0062-0.35-IFR	0.35 GPM Inline Flow Regulator with 3/8" Compression Fitting
EX0062-0.5-IFR	0.5 GPM Inline Flow Regulator with 3/8" Compression Fitting

Disconnect Switch

MODEL NUMBER	DESCRIPTION
EX68031-15	Disconnect Switch, Rotary, upto 30A, 3P, UL508, Mersen #EJM30BS0
EX68031-16	Disconnect Switch, Rotary, upto 63A, 3P, UL508, Socomec #22243506

Replacement Parts – Excluding Elements

MODEL NUMBER	DESCRIPTION
CIRCUIT BOARDS	
EX284E-309-240-KIT	208V/240V Thermostatic Circuit Board For EX0309-240V Display Board – legacy HomeAdvantage/ProAdvantage
EX284-309-120V	120V Thermostatic Circuit Board - ProAdvantage
EX0309-240V	Display Board w/Push Button Temperature Control – legacy HomeAdvantage/ProAdvantage
EX284-309-277V	277V Thermostatic Circuit Board - ProAdvantage
EX0183DL-30A	208/240/277V Circuit Board legacy Flow Controlled and legacy Single Point 30 Amp for units under 6.5kW
EX0183DL-40A	208/240/244V Circuit Board legacy Flow Controlled and legacy Single Point for units over 6.5 kW
EX100S-208V-KIT	208/277V Dual Voltage Secondary Board
EX284AB-120-KIT	120V Thermostatic Circuit Board for legacy Series 1 thermostatic units only
EX284AB-120ML-KIT	120V Thermostatic circuit board Multiple Lavatory for legacy Series 1 thermostatic units only
EX284AB-240-KIT	240V Thermostatic Circuit Board for legacy thermostatic units only
EX284AB-240ML-KIT	240V Thermostatic Circuit Board Multiple Lavatory for legacy thermostatic units only
EX284AB-277-KIT	277V Thermostatic Circuit Board for legacy thermostatic units only
EX284AB-277ML-KIT	277V Thermostatic Circuit Board For Multiple Lavatory for legacy thermostatic units only
EX100CV-480V	480V Delta Thermostatic Control Board – Primary
EX100S-480V	480V Delta Thermostatic Control Board – Secondary
EX383	FlowCo Control Board (Must provide unit model number, ex. SPEX1812)
EX384-120	120V LavAdvantage/AccuMix II Control Board (Must provide unit model number, ex. SPEX2412T)
EX384-240	240V LavAdvantage/AccuMix II Control Board (Must provide unit model number, ex. SPEX55T)
EX384-277	277V LavAdvantage/AccuMix II Control Board (Must provide unit model number, ex. SPEX80T)
TRIACS	
EX18-KIT	Triac – Includes triac, backing plate, O-ring, thermoconductive grease, and instructions
ECO	
EX08100-02	ECO – Tepid temperature range – for 480V product only
EX08100-03	ECO – Standard Temperature Range – for 480V product and 'CA' suffix product only
EX08100-04	ECO – Sanitation Temperature Range – for 480V product only
EX278A-KIT	ECO – Standard Temperature Range – Includes ECO, backing plate, O-ring, thermoconductive grease, and instructions
EX278D-KIT	ECO – Sanitation Temperature range – (yellow dot) Sanitize Units Includes ECO, backing plate, O-ring, thermoconductive grease, and instructions
EX278E-KIT	ECO Tepid Temperature range – Emergency Eye Wash, Face wash, Drench Shower. Includes ECO, backing plate, O-ring, thermoconductive grease, and instructions
RELAYS	
EX08002-01	Contactors 480 V 40-amp 3-pole for ED020480T2T, ED020480T3, ED024480T2T, ED024480T3, ED032480T2T, and ED032480T3
EX1050-1	Contactors 240 V 50-amp 2-pole for SPEX012240T, AM012240T, EX012240T, MB012240T, EX023240TC, and EX023240T2
EX250B	Relay 120 V 30-amp 2-pole for SPEX1812, SPEX1812CA, SPEX2412, SPEX2412CA, SPEX3012, SPEX3012CA, SPEX3512, SPEX3512 CA, SP3012, SP3512, EX2412, EX3012, and EX3512
EX251B	Relay 277 V 30-amp 2-pole for SPEX3277, SPEX3277CA, SPEX4277, SPEX4277CA, SPEX60, SPEX60 CA, SPEX80, SPEX80CA, SP3277, SP4277, SP60, and SP80
EX253B	Relay 277 V 40-amp 2-pole for SPEX3277, SPEX4277, SPEX60T, SPEX80T, SPEX90T, SPEX100T, AM004277T, AM008277T, AM010277T, SPEX90, SPEX90CA, SPEX100, SPEX100CA, EX3277T, EX4277T, EX60T, EX80T, EX90T, EX100T, MT004277T, MT008277T, MT010277T, MB004277T, MB008277T, MB010277T, EX90, EX100, EX160TC, EX200TC, EX200TC, PA008277T, PA010277T, PA016277TC, PA020277TC, SPEX3277T DI, SPEX4277T DI, SPEX60T DI, SPEX80T DI, SPEX90T DI, SPEX100T DI, EX3277T DI, EX4277T DI, EX60T DI, EX80T DI, EX90T DI, EX100T DI, EX160TC DI, EX160TC DI, EX200T2 DI, and EX200T2 DI
EX254	Relay 240 V 30-amp 2-pole for SPEX35, SPEX35CA, SPEX48, SPEX48CA, SPEX55, SPEX55CA, SPEX65, SPEX65CA, SP35, SP48, SP55, SP65, EX35, EX48, EX55, and EX65
EX254B	Relay 208 V 30-amp 2-pole for SPEX3208, SPEX3208CA, SPEX4208, SPEX4208CA, SP35, SP48, EX35, and EX48
EX255B	Relay 240 V 40-amp 2-pole for SPEX3208T, SPEX35T, SPEX4208T, SPEX55T, SPEX65T, SPEX75T, SPEX8208T, SPEX95T, AM005240T, AM007240T, AM010240T, SPEX75, SPEX75CA, SPEX8208, SPEX8208CA, SPEX95, SPEX95CA, SP75, SP8208, SP95, EX3208, EX3208T, EX35T, EX35T, EX4208T, EX48T, EX55T, EX65T, EX75T, EX8208T, EX95T, EX75, EX8208, EX95, MT005240T, MT007240T, MT010240T, MB005240T, MB007240T, MB010240T, EX1608TC, EX1608TC CNL, EX1608T2, EX144TC, EX144TC CNL, EX144T2, EX144T2 CNL, EX190TC, EX190TC CNL, EX190T2, EX190T2 CNL, EX280T2, EX280T2 CNL, EX280T3, EX280T3 CNL, EX380T4, PA005240T, PA007240T, PA008208T, PA010240T, PA014240TC, PA019240TC, PA028240T2T, SS015240TC, SS019240TC, SS029240T2T, SS038240T2T2, SPEX35T DI, SPEX48T DI, SPEX55T DI, SPEX65T DI, SPEX75T DI, SPEX8208T DI, SPEX95T DI, EX35T DI, EX48T DI, EX55T DI, EX65T DI, EX75T DI, EX8208T DI, EX95T DI, EX1608TC DI, EX1608T2 DI, EX144TC DI, EX144T2 DI, EX190TC DI, EX190T2 DI, EX280T2T DI, and EX280T3 DI
EX256	Relay 208 V 75-amp 3-pole for EX240T2T, EX240T3, EX240T2T, EX240T3, PA024208T2T, PA024208T2T, EX240T2T DI, EX240T3 DI, EX240T2T DI, and EX240T3 DI
EX257B	Relay 277V 50-amp 4-pole for EX240T2T-277, EX240T3-277, EX240T2-277, EX240T3-277, EX320T2T-277 DI, EX320T2T-277 DI, EX320T2T-277 DI, PA024277T2T, PA024277T2T, PA032277T2T, EX240T2T-277 DI, EX240T3-277 DI, EX240T2T-277 DI, EX240T3-277 DI, EX320T2T-277 DI, and EX320T2T-277 DI
EX259B	Relay 120 V 30-amp 2-pole for SPEX1812T, SPEX2412T, SPEX3012T, SPEX3512T, AM004120T, EX2412T, EX3012T, EX3512T, MT004120T, MB004120T, PA004120T, SPEX1812T DI, SPEX2412T DI, SPEX3012T DI, SPEX3512T DI, EX2412T DI, EX3012T DI, and EX3512T DI

Accessories and Replacement Parts

Continued

Replacement Parts – Heating Elements

MODEL NUMBER	ELEMENT CARTRIDGE
ACCUMIX II MODELS	
AM004120T	EX410
AM005240T	EX1200
AM007240T	EX890
AM010240T	EX630
AM004277T	EX1870
AM008277T	EX960
AM010277T	EX760
AM012240T	EX500 PRT
LAVADVANTAGE AND FLOWCO MODELS	
SPEX1812(T)	EX800 PRT
SPEX2412(T)	EX610
SPEX3012(T)	EX480
SPEX3512(T)	EX410
SPEX3208(T)	EX1440
SPEX4208(T)	EX1050
SPEX8208(T)	EX520
SPEX35(T)	EX1650
SPEX48(T)	EX1200
SPEX55(T)	EX1050
SPEX65(T)	EX890
SPEX75(T)	EX770
SPEX95(T)	EX630
SPEX012240T	EX500 PRT
SPEX3277(T)	EX260
SPEX4277(T)	EX1870
SPEX60(T)	EX1280
SPEX80(T)	EX960
SPEX90(T)	EX850
SPEX100(T)	EX760
MINITANK MODELS	
EMT1, EMT2.5, EMT4, EMT6	Contact Eemax Customer Experience for assistance
SERIES TWO MODELS	
EX120 (T2, TC)	EX1000
EX144 (T2, TC)	EX770
EX190 (T2, TC)	EX630
EX023240 (T2, TC)	EX500 PRT
EX1608 (T2, TC)	EX520
EX160 (T2, TC)	EX960
EX200 (T2, TC)	EX760
PROADVANTAGE MODELS	
PA004120T	EX410
PA008208T	EX520
PA005240T	EX1200
PA007240T	EX890
PA010240T	EX630
PA012240T	EX500 PRT
PA008277T	EX960
PA010277T	EX760
PA014240TC	EX770
PA016277TC	EX960
PA019240TC	EX630
PA020277TC	EX760
PA023240TC	EX500 PRT
PA028240T2T	EX630
PA018208T2T	EX720
PA024208T2T	EX560
PA018277T2T	EX1260
PA024277T2T	EX960
PA032277T2T	EX720

MODEL NUMBER	ELEMENT CARTRIDGE
THREE PHASE MODELS	
EX180(T2T, T3) 277V	EX1280
EX180(T2T, T3) 208V	EX720
EX240(T2T, T3) 277V	EX960
EX240(T2T, T3) 208V	EX560
EX320(T2T, T3) 277V	EX720
ED020480(T2T, T3) 480V	EX3454
ED024480(T2T, T3) 480V	EX2880
ED032480(T2T, T3) 480V	EX2194
ACCUMIX MODELS	
MT004120T, MB004120T	EX410
MT005240T, MB005240T	EX1200
MT007240T, MB007240T	EX890
MT010240T, MB010240T	EX630
MT004277T, MB004277T	EX1870
MT008277T, MB008277T	EX960
MT010277T, MB010277T	EX760
MB012240T	EX500 PRT
SERIES ONE 'SP-' MODELS	
SP2412	EX610
SP3012	EX480
SP3512	EX410
SP3208	EX1440
SP4208	EX1050
SP35	EX1650
SP48	EX1200
SP55	EX1050
SP65	EX890
SP75	EX770
SP95	EX630
SP3277	EX260
SP4277	EX1870
SP60	EX1280
SP80	EX960
SP90	EX850
SP100	EX760
SERIES ONE 'EX-' MODELS	
EX2412(T)	EX610
EX3012(T)	EX480
EX3512(T)	EX410
EX3208(T)	EX1440
EX4208(T)	EX1050
EX8208(T)	EX520
EX35(T)	EX1650
EX48(T)	EX1200
EX55(T)	EX1050
EX65(T)	EX890
EX75(T)	EX770
EX95(T)	EX630
EX012240T	EX500 PRT
EX3277(T)	EX260
EX4277(T)	EX1870
EX60(T)	EX1280
EX80(T)	EX960
EX90(T)	EX850
EX100(T)	EX760
SERIES THREE MODELS	
EX280 (T2T, T3)	EX630
SERIES FOUR MODELS	
EX380 (T2T2, T4)	EX630

Accessories and Replacement Parts

Continued

SpecAdvantage and SafeAdvantage Replacement Parts Listed By Model

MODEL NUMBER	MODEL NUMBER SUFFIX	ELEMENT NUMBER ASSEMBLY*	FLOW METER ASSEMBLY (INC BOARD)	PRIMARY DISPLAY BOARD*	TRANSFORMER	FUSES	SSR MANIFOLD ASSEMBLY	ECO ASSEMBLY	OPTICAL BOARD ASSEMBLY
VOLTS 208 Three Phase Delta									
AP032208		EX77000-8.12B02	EX78000-00	EX08300-00	EX08303-13	EX198	†	EX278A-KIT	EX78001-00
AP032208	EE	EX77000-8.12A04	EX78000-01	EX08300-00	EX08303-13	EX198	†	EX278E-KIT	EX78001-00
AP032208	S	EX77000-8.12B00	EX78000-00	EX08300-00	EX08303-13	EX198	†	EX278D-KIT	EX78001-00
AP036208		EX77000-7.20B02	EX78000-00	EX08300-00	EX08303-13	EX08200-11	†	EX278A-KIT	EX78001-00
AP036208	EE	EX77000-7.20A04	EX78000-01	EX08300-00	EX08303-13	EX08200-11	†	EX278E-KIT	EX78001-00
AP036208	S	EX77000-7.20B00	EX78000-00	EX08300-00	EX08303-13	EX08200-11	†	EX278D-KIT	EX78001-00
AP041208		EX77000-6.33B02	EX78000-00	EX08300-00	EX08303-13	EX08200-11	†	EX278A-KIT	EX78001-00
AP041208	EFD	EX77000-6.33A04	EX78000-01	EX08300-00	EX08303-13	EX08200-11	†	EX278E-KIT	EX78001-00
AP041208	S	EX77000-6.33B00	EX78000-00	EX08300-00	EX08303-13	EX08200-11	†	EX278D-KIT	EX78001-00
AP054208		EX77000-4.81B02	EX78000-00	EX08300-00	EX08303-13	EX198	†	EX278A-KIT	EX78001-00
AP054208	EFD	EX77000-4.81A04	EX78000-01	EX08300-00	EX08303-13	EX198	†	EX278E-KIT	EX78001-00
AP054208	S	EX77000-4.81B00	EX78000-00	EX08300-00	EX08303-13	EX198	†	EX278D-KIT	EX78001-00
AP064208		EX77000-4.06B04	EX78000-01	EX08300-00	EX08303-13	EX08200-11	†	EX278A-KIT	EX78001-00
AP064208	EFD	EX77000-4.06A04	EX78000-01	EX08300-00	EX08303-13	EX08200-11	†	EX278E-KIT	EX78001-00
AP064208	S	EX77000-4.06B00	EX78000-01	EX08300-00	EX08303-13	EX08200-11	†	EX278D-KIT	EX78001-00
VOLTS 480 Three Phase Delta									
AP036480		EX77000-19.2B02	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278A-KIT	EX78001-00
AP036480	EE	EX77000-19.2A04	EX78000-01	EX08300-00	EX08303-05	N/A	†	EX278E-KIT	EX78001-00
AP036480	S	EX77000-19.2B00	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278D-KIT	EX78001-00
AP039480		EX77000-17.7B02	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278A-KIT	EX78001-00
AP039480	EE	EX77000-17.7A04	EX78000-01	EX08300-00	EX08303-05	N/A	†	EX278E-KIT	EX78001-00
AP039480	S	EX77000-17.7B00	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278D-KIT	EX78001-00
AP048480		EX77000-14.4B02	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278A-KIT	EX78001-00
AP048480	EFD	EX77000-14.4A04	EX78000-01	EX08300-00	EX08303-05	N/A	†	EX278E-KIT	EX78001-00
AP048480	S	EX77000-14.4B00	EX78000-00	EX08300-00	EX08303-05	N/A	†	EX278D-KIT	EX78001-00
AP054480		EX77000-12.8B04	EX78000-00	EX08300-00	EX08303-08	EX08100-07	†	EX278A-KIT	EX78001-00
AP054480	EFD	EX77000-12.8A04	EX78000-01	EX08300-00	EX08303-08	EX08100-07	†	EX278E-KIT	EX78001-00
AP054480	S	EX77000-12.8B00	EX78000-00	EX08300-00	EX08303-08	EX08100-07	†	EX278D-KIT	EX78001-00
AP063480		EX77000-18.2B04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278A-KIT	EX78001-00
AP063480	EFD	EX77000-18.2A04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278E-KIT	EX78001-00
AP063480	S	EX77000-18.2B00	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278D-KIT	EX78001-00
AP072480		EX77000-19.2B04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278A-KIT	EX78001-00
AP072480	EFD	EX77000-19.2A04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278E-KIT	EX78001-00
AP072480	S	EX77000-19.2B00	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278D-KIT	EX78001-00
AP096480		EX77000-14.4B04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278A-KIT	EX78001-00
AP096480	EFD	EX77000-14.4A04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278E-KIT	EX78001-00
AP096480	S	EX77000-14.4B00	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278D-KIT	EX78001-00
AP108480		EX77000-12.8B04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278A-KIT	EX78001-00
AP108480	EFD	EX77000-12.8A04	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278E-KIT	EX78001-00
AP108480	S	EX77000-12.8B00	EX78000-01	EX08300-00	EX08303-08	EX198	†	EX278D-KIT	EX78001-00
AP126480		EX77000-10.97B04	EX78000-01	EX08300-00	EX08303-08	EX08200-11	†	EX278A-KIT	EX78001-00
AP126480	EFD	EX77000-10.97A04	EX78000-01	EX08300-00	EX08303-08	EX08200-11	†	EX278E-KIT	EX78001-00
AP126480	S	EX77000-10.97B00	EX78000-01	EX08300-00	EX08303-08	EX08200-11	†	EX278D-KIT	EX78001-00
AP144480		EX77000-9.6B04	EX78000-01	EX08300-00	EX08303-08	EX08200-13	†	EX278A-KIT	EX78001-00
AP144480	EFD	EX77000-9.6A04	EX78000-01	EX08300-00	EX08303-08	EX08200-13	†	EX278E-KIT	EX78001-00
AP144480	S	EX77000-9.6B00	EX78000-01	EX08300-00	EX08303-08	EX08200-13	†	EX278D-KIT	EX78001-00
VOLTS 600 Three Phase Delta									
AP061600		EX77000-8.85B04	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278A-KIT	EX78001-00
AP061600	EFD	EX77000-8.85A04	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278E-KIT	EX78001-00
AP061600	S	EX77000-8.85B00	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278D-KIT	EX78001-00
AP071600		EX77000-7.61B04	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278A-KIT	EX78001-00
AP071600	EFD	EX77000-7.61A04	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278E-KIT	EX78001-00
AP071600	S	EX77000-7.61B00	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278D-KIT	EX78001-00
AP102600		EX77000-24.2B04	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278A-KIT	EX78001-00
AP102600	EFD	EX77000-24.2A04	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278E-KIT	EX78001-00
AP102600	S	EX77000-24.2B00	EX78000-01	EX08300-00	EX08303-06	EX08200-08	†	EX278D-KIT	EX78001-00
AP130600		EX77000-16.4B04	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278A-KIT	EX78001-00
AP130600	EFD	EX77000-16.4A04	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278E-KIT	EX78001-00
AP130600	S	EX77000-16.4B00	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278D-KIT	EX78001-00
AP150600		EX77000-14.4B04	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278A-KIT	EX78001-00
AP150600	EFD	EX77000-14.4A04	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278E-KIT	EX78001-00
AP150600	S	EX77000-14.4B00	EX78000-01	EX08300-00	EX08303-06	EX08200-13	†	EX278D-KIT	EX78001-00

† For units up to serial number 2635795 use EX78000-00. For units after serial number 2635795 use EX78000-01.

* If ordering elements or primary display boards for a heater you must provide the serial number.

Accessories and Replacement Parts

Continued

HomeAdvantage II, ProSeries, and AutoBooster Replacement Parts

MODEL NUMBER	FOR USE WITH
HEATING ELEMENTS	
HA-P001	Element, Heating for HA011240 and PR001140
HA-P002	Element, Heating for HA013240 and PR001340
HA-P003	Element, Heating for HA008240 and PR000840
HA-P004	Element, Heating for HA024240 and PR002440
HA-P005	Element, Heating for HA018240, HA027240, HA036240, PR018240, PR27240, and PR036240
HA-P074	Element, Heating for HATB007240
TRIACS	
HA-P008	Triac, 1st Heating Element for HA008240/HA011240/HA013240 PR008240, PR011240, and PR013240
HA-P009	Triac, 2nd Heating Element for HA011240/HA013240, PR011240, and PR013240
HA-P010	Triac, 1st Heating Element for HA018240 and PR018240
HA-P011	Triac, 2nd Heating Element for HA018240 and PR018240
HA-P012	Triac, 3rd Heating Element for HA024240/HA027240, PR024240, and PR027240
HA-P053	Triac, 1st Heating Element for HA024240, HA027240, PR024240, and PR027240
HA-P054	Triac, 1st Heating Element for HA036240 and PR036240
HA-P055	Triac, 2nd Heating Element for HA024240, HA027240, PR024240, and PR027240
HA-P056	Triac, 2nd Heating Element for HA036240 and PR036240
HA-P057	Triac, 3rd Heating Element for HA036240 and PR036240
HA-P051	Triac, 4th Heating Element for HA036240
HA-P080	Triac for HATB007240
FLOW SENSORS	
HA-P021	Flow Sensor Assembly (no housing) for HA008240, HA011240, HA013240, PR008240, PR011240, and PR013240
HA-P022	Flow Sensor Assembly for 1st generation (engineered plastic body) HA018240/HA024240/HA027240/HA036240, PR018240, PR024240, PR027240, and PR036240
HA-P136	Flow Sensor and Insert for 2nd Generation (brass body) HA018240, HA024240, HA027240, HA036240, PR018240, PR024240, PR027240, and PR036240
CONTROL BOARDS	
HA-P024-008	Control Board for HA008240 w/Transformer
HA-P024-008-PRO	Control board for PR008240 w/Transformer
HA-P024-011	Control Board for HA011240 w/Transformer
HA-P024-011-PRO	Control board for PR011240 w/Transformer
HA-P024-013	Control Board for HA013240 w/Transformer
HA-P024-013-PRO	Control board for PR013240 w/Transformer
HA-P025	Control Board for HA018240/HA027240/HA036240
HA-P025-PRO	Control board for PR018240, PR027240, and PR036240
HA-P025-024	Control Board for HA024240
HA-P025-024-PRO	Control Board for PR024240
HA-P075	Control board with relay for HATB007240
ECO'S	
HA-P033	ECO for HA008240, HA011240, HA013240, PR008240, PR011240, PR013240, and HATB007240
HA-P148	ECO for HA018240, HA024240, HA027240, and HA036240
HA-P149	ECO for PR018240, PR024240, PR027240, and PR036240
THERMISTORS	
HA-P006	Thermistors – inlet and outlet – for HA008240, HA011240, HA013240, PR008240, PR011240, and PR013240
HA-P046	Thermistors – inlet and outlet – for HA018240, HA024240, HA027240, PR018240, PR024240, and PR027240 with flow meters with plastic covers
HA-P047	Thermistors – inlet and outlet – for HA036240 and PR036240 with flow meters with plastic covers
HA-P081	Thermistors – inlet and outlet – for HATB007240
HA-P134	Thermistors – inlet and outlet - for HA018240, HA024240, HA027240, PR018240, PR024240, and PR027240 with brass body flow meters
HA-P135	Thermistors – inlet and outlet – for HA036240 and PR036240 with brass body flow meters
MISC ITEMS	
HA-P026	Knob for HA008240/HA011240/HA013240, PR008240, PR011240, PR013240, and HATB007240
HA-P027	Knob for HA018240/HA024240/HA027240/HA036240, PR018240, PR024240, PR027240, and PR036240
HA-P028	Fuse .187A fast-acting for HA018240, HA024240, HA027240, HA036240, PR018240, PR024240, PR027240, and PR036240 with external fuseholder
HA-P062	Fuseholder with wires for HA018240, HA024240, HA027240, HA036240, PR018240, PR024240, PR027240, and PR036240 with external fuseholder
HA-P066-KIT	NPT Adapter kit Includes (set of 2): NPT adapters 1/2" compression to 1/2" NPT adaptor, 1/2" compression nut, and 1/2" compression ferrule for HA008240, HA011240, HA013240, PR008240, PR011240, and PR013240
HA-P073	Power supply cable HATB007240 to electric tank
HA-P083	Inlet and outlet fittings. Inlet fitting: 3/4" x 14 FNPT to 1/2" compression; outlet fitting: 3/4" x 14 MNPT to 1/2" compression; (2) 1/2" compression nuts and (2) 1/2" compression ferrules for HATB007240
HA-P092	Fuse 0.2A 250V time-delay for HA018240, HA024240, HA027240, HA036240, PR018240, PR024240, PR027240, and PR036240 with fuse on circuit board

Accessories and Replacement Parts

Continued

ProSeries XTP Replacement Parts

MODEL NUMBER	FOR USE WITH
FLOW METER	
EX76042-02	Turbine Flow Meter for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
HEATING ELEMENTS	
EX05502-00	Element, heating for XTP018208
EX05502-01	Element, heating for XTP024208
EX05502-02	Element, heating for XTP032208
EX05502-03	Element, heating for XTP016480
EX05502-04	Element, heating for XTP020480
EX05502-05	Element, heating for XTP024480
EX05502-06	Element, heating for XTP027480
EX05502-07	Element, heating for XTP036480
HA-P004	Element, heating for XTP048480
HA-P005	Element, heating for XTP054480
CONTACTOR	
EX08100-10	Contactor 208V 75-amp for XTP018208, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
SOLID STATE RELAY	
EX08200-12	Solid state relay 50-amp for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
THERMISTORS	
EX08200-16	Inlet Thermistor for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
EX08200-17	Outlet Thermistor for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
TRANSFORMERS	
EX08303-13	Control transformer 208 V for XTP018208, XTP024208, and XTP032208
EX08303-08	Control transformer 480 V for XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
CIRCUIT BOARD	
EX09100-001	Master Display Board for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480
ECO	
EX279D-KIT	ECO – Standard Temperature range for ProSeries XTP. Includes ECO, backing plate, O-ring, thermoconductive grease, and instructions for XTP018240, XTP024208, XTP036208, XTP016480, XTP020480, XTP024480, XTP027480, XTP036480, XTP048480, and XTP054480