



FIRECLAY GENERAL CARE & CLEANING

BLANCO Fireclay sinks are designed for simple and easy care and cleaning.

For everyday dirt and stains we recommend a mild dish soap or detergent with warm water and use of a soft cloth. Rinse thoroughly after cleaning and dry with a soft dry cloth to restore original luster of material.

For harder to clean stains, we recommend using 50/50 water and bleach solution or a non-abrasive cleaner. Rinse thoroughly after cleaning and dry with a soft dry cloth.

Do not use harsh abrasive or caustic cleaners containing ammonia or alkalis to clean sink surface. Do not use materials such as scouring pads, steel wool, abrasive powder or liquid cleaners when cleaning the sink surface. Do not use paint removers, over cleaners or aggressive chemical solutions to clean sink surface.

For questions or further information:

BLANCO CUSTOMER SERVICE

CALL: 1-800-451-5782

FAX: 1-800-213-1963

EMAIL: blanco@blancoamerica.com