


# Exploded Views and Parts List

## INDOOR UNIT

AR12HSFSJWKNCV



■ Parts List (04 FRAME PART LIST)

Exploded Views and Parts List

NO	Parts Code	Parts Description	Quantity	Service
			AR09FSHSJWKNCV	
1	DB61-05853A	HOLDER-PIPE	1	SA
2	4301-000121	BATTERY-MN	2	SA
3	DB90-07732A	ASSY HANGER	1	SA
4	DB61-05829A	HOLDER EVAP	1	SNA
5	DB94-04149H	ASSY BACK BODY	1	SA
5-1	DB61-05849A	HOLDER	1	SA
5-2	DB61-05854A	CASE PCB-REMOCON	1	SNA
5-3	DB61-05824B	BODY BACK	1	SNA
5-4	DB92-02874A	ASSY PCB SUB	1	SA
6	DB63-03494A	COVER PANEL-SUB	1	SA
7	DB94-04357A	ASSY FILTER-PRE	1	SA
7-1	DB63-03522A	FILTER-PRE	1	SA
8	DB67-01404B	CAP-SCREW	2	SNA
9	DB90-07762B	ASSY COVER-PANEL	1	SNA
9-1	DB63-03488B	COVER PANEL	1	SNA
9-2	DB64-03045A	BUTTON POWER	1	SA
10	DB92-02887B	ASSY GRILLE	1	SA
11	DB92-02888B	ASSY PANEL FRONT	1	SNA
11-1	DB92-02889A	ASSY PANEL-SUB	1	SA
12	DB90-07861A	ASSY PLATE-MIDDLE	1	SA
12-1	DB61-06079A	PLATE CONTROL-MIDDLE	1	SC
13	DB93-14734E	ASSY CONTROL IN	1	SNA
13-1	DB90-08173C	ASSY CASE CONTROL IN	1	SNA
13-1-1	DB61-05812A	PLATE CONTROL-SUB	1	SA
13-1-2	DB61-05963A	SUPPORT-CONTROL	1	SA
13-1-3	DB65-00326D	TERMINAL BLOCK	1	SA
13-1-4	DB93-06677A	ASSY CONNECTOR WIRE	1	SA
13-1-5	DB93-14207B	ASSY CONNECTOR WIRE-DC SIGNAL	1	SA
13-1-6	DB93-14245A	ASSY CONNECTOR WIRE-EARTH	1	SA
13-2	DB92-02861A	ASSY MODULE	1	SA
13-3	DB92-02873C	ASSY PCB MAIN	1	SA
13-4	DB93-14209B	ASSY CONNECTOR WIRE-DISPLAY	1	SA
13-5	DB93-14211A	ASSY CONNECTOR WIRE-DC SIGNAL	1	SA
13-6	DB93-14221A	ASSY CONNECTOR WIRE-DC SIGNAL	1	SA
13-7	DB93-14723A	ASSY CONNECTOR WIRE-DC SIGNAL	1	SA
13-8	DB93-14724A	ASSY CONNECTOR WIRE-MOTOR	1	SA
14	DB92-02877A	ASSY PCB DISPLAY	1	SA
15	DB31-00636A	MOTOR BLDC FAN	1	SA
16	DB63-03492A	COVER MOTOR	1	SA
17	DB94-00455B	ASSY-RUBBER BEARING	1	SC
18	DB94-01550E	ASSY FAN CROSS	1	SA
19	DB64-02991A	WINDOW DISPLAY	1	SA
20	DB94-04148B	ASSY TRAY DRAIN	1	SA
20-1	DB31-00369D	MOTOR STEP	1	SA
20-2	DB94-00458H	ASSY HOSE DRAIN	1	SA
20-3	DB61-05827A	CASE-DISPLAY	1	SA
20-4	DB61-05846A	BLADE V	17	SA
20-5	DB63-03487A	TRAY DRAIN	1	SNA
20-6	DB61-05872A	GUIDE BLADE	1	SA
20-7	DB63-03530A	GUARD-SCREEN	1	SNA
20-8	DB66-01726A	LINK BLADE-A	1	SNA
20-9	DB66-01730A	LINK BLADE-B	1	SA
20-10	DB73-00180B	RUBBER-CAP DRAIN	1	SA
20-11	DB92-02890A	ASSY BLADE H	1	SA
20-12	DB61-03132A	HOLDER-BLADE OUT	1	SNA
21	DB67-60030A	SPRING-SENSOR	2	SA
22	DB96-18999B	ASSY EVAP TOTAL	1	SA
22-1	DB96-18944A	ASSY TUBE EVAP IN	1	SA
22-2	DB96-18945A	ASSY TUBE EVAP OUT	1	SA
23	DB63-03510A	COVER EVAP	1	SA
24	DB93-14195G	ASSY WIRELESS REMOCON	1	SA
25	DB61-05958A	HANGER-LINK	1	SA
26	DB92-02873C	ASSY PCB MAIN	1	SA
27	DB93-14203A	ASSY CONNECTOR WIRE-POWER	1	SA
28	DB61-05959A	PLATE CONTROL-RIGHT	1	SA
29	DB67-01431A	RUBBER PIPE	1	SA
30	DB93-14208A	ASSY CONNECTOR WIRE-DC SIGNAL	1	SA
31	DB90-07763A	ASSY-WIFI KIT	1	SNA
31-1	DB61-05847A	CASE PCB	1	SA
31-2	DB63-03503A	COVER PCB	1	SA
31-3	DB92-02875A	ASSY PCB SUB	1	SA
32	DB95-05163A	ASSY THERMISTOR IN	1	SA
33	DB61-05965A	PLATE CONTROL-UP	1	SA