

For faucets with outside threads,

Install onto spout by hand.