

INSTRUCTIONS:

1. Remove aerator from faucet. If a wrench is necessary, place cloth over aerator to prevent damage.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads on faucet for easier installation.
4. Install adapter onto spout by hand.
5. Connect your regular female aerator or any device with regular female threads.
6. Turn on faucet. If leak occurs, tighten more firmly.

INSTRUCCIONES:

1. Quite el aireador del grifo. Si se necesita una llave inglesa, coloque un trapo sobre el aireador para evitar daños.
2. Quite todas las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las roscas del grifo para una instalación más fácil.
4. Instale el adaptador en forma manual.
5. Conecte su aireador regular hembra o cualquier dispositivo con roscas hembra regular.
6. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.