


■ Order by Part Number


Stopper - Polished Stainless  
1011



Removable Splash Guard  
1016




Sink Flange - Polished Stainless  
1017




### Mounting Assembly Kit - 1824

Fiber Gasket  
Backup Flange  
Screws (x3)  
Mounting Ring  
Snap Ring  
Cushion Mount  
Lower Mounting Ring





### Drain Elbow Kit - 1026

Rubber Gasket  
Screws  
Drain Elbow



### Single Snap Assembly Kit - 193800

Simple Snap Tool  
Snap Ring  
Replacement Power Cord Kit  
1024


## Garbage Disposals

MODEL EXL100c

### Other Available Accessories



#### Air Switch Remote Controller

- Installs into existing sink hole to operate disposer with plunger air switch.
- Perfect application for island countertops or where electrical switch is unavailable.
- No wiring connections or code restrictions.

#### Air Switch Base Unit

Air Switch Remote Controller	ARC-4200
Additional Air Switch Button Finish Options:	
Chrome	AS-4201-CH
Satin Nickel	AS-4201-SN
Mediterranean Bronze	AS-4201-BRB
Polished Brass	AS-4201-BR
White	AS-4201-WH
Almond	AS-4201-AL
Biscuit	AS-4201-BIS
Matte Black	AS-4201-BL
Brushed Gold	AS-4201-BG
Polished Nickel	AS-4201-NL

#### Optional:


Dishwasher Connector Kit

1023



Unjamming Wrench

1037



Light Collar Replacement

195182

