


Recirculation Mode

[Crossover(CrOS) Mode]

- Provides recirculation option for homes without a dedicated return line by utilizing the cold water line as a return line.
- Timer can be manually customized or programmed to automatically learn daily usage patterns.
- In order to prevent hot water from being supplied into the cold water line, the thermal element in the crossover valve will close at 95F. As a result, hot water may not be available at all times (only warm water).



Dedicated Return Line	Accessory	Setting		Maximum Loop Length		Controlled by
		1 : RM	2 : RM	1/2"	3/4"	
NO	cCS-V	ON	CrOS	200' (60m)	500' (150m)	Timer