



Welcome to BISSELL

air400



air600
006

bissell

Safety Instructions

WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY:

Use indoors only

Do not use for any purpose other than described in this user's guide.

Use only Manufacturer's recommended accessories.

Do not use with damaged cord or plug.

If appliance is not working as it should, or has been dropped, damaged, left outdoors, or dropped into water, have it repaired at an authorized service center.

Do not move or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp corners. Keep cord away from heated surfaces

Do not run cord under carpeting. Do not cover cord with throw rugs, runners or similar coverings. Arrange cord away from traffic areas so it will not be tripped over

Do not unplug by pulling cord. To unplug, grasp the plug, not the cord.

Do not handle plug or appliance with wet hands.

Do not put any object into openings. Do not use with any opening blocked; keep openings free of dust, lint, hair and anything that may reduce airflow.

Keep hair, loose clothing and fingers away from openings.

Turn off device controls before unplugging the appliance.

Do not use appliance in an enclosed space filled with vapors given off by oil based paint, paint thinner, moth proofing substances, flammable dust or other explosive or toxic vapors.

Keep appliance on a level surface.

Do not immerse the unit in waters or other liquids, do not pour liquids into or around the unit or openings.

Do not use the appliance near water or in a damp or wet location

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Do not use the appliance with any dimmer switch or solid state speed control device.

Read & Save These Instructions

WARNING


This model is for household use only.

Plastic film can be dangerous. To avoid danger of suffocation, keep away from children.

Do not plug in your air purifier UNTIL you are familiar with all instructions and operating procedures.

To reduce the risk of electrical shock, turn power switch off and disconnect polarized plug from electrical outlet BEFORE performing maintenance or troubleshooting checks.

Control Panel



Fan Speed Settings

Press Fan Speed button to select desired fan speed.


- Press once to select LOW fan speed.
- Press twice to select MEDIUM fan speed.
- Press three times to select HIGH speed fan.



Timer Settings

Press Timer button to select desired timer option.

- Press once to select 1 hour.
- Press twice for 4 hours.
- Press three times to select 8 hours.



Filter Reset Settings


After replacing either filter, press and hold the filter reset button for 3 seconds.



Filter Change Indicators

1 - Activated Carbon filter
2 - HEPA + Pre filter

Mode Descriptions



Max

In Max mode, the air purifier operates at its maximum speed. This mode is best for quick cleaning.

Auto

When powered on, the **BISSELL air400** will default to auto mode. This mode prompts the air purifier to adjust to an ideal filtration level based on the quality of your indoor air as detected by the CirQulate™ System.

Silent

In Silent mode, air purification is delivered at Library Quiet sound levels, offering a peaceful and calm room setting. This mode is most ideal for sleeping environments.


Night Mode

Night mode is activated by a light sensor. As less light saturates a room, both the white lights on the control panel and the air quality feedback display will turn off. The color wheel will dim. This contributes to a peaceful sleeping environment.

NOTE: When the air purifier goes into night mode, it will remain in which ever mode or fan speed it was set to before going into night mode.

Maintenance & Care

Filter Replacement




⚠ For your safety, always turn off and unplug your air purifier before replacing filters.

Each filter has blue easy pull tabs. The tabs should face outward. Insert activated carbon filter before inserting HEPA + pre-filter. The pre-filter attached to the HEPA filter should face outward.

NOTE: Filter life varies based on runtime and existing air conditions. It is recommended to replace both the HEPA + pre-filter and activated carbon filter once every six months.

Particulate Sensor Cleaning



For accurate air quality display readings, the blue sensor screen should be gently cleaned with a cotton swab once every two weeks.

cirQulate™ System

When set to **Auto Mode**, the BISSELL air400 uses its CirQulate™ System to provide optimum filtration based on the air quality in your home.

CirQulate™ uses the air400's PM 2.5 sensor to measure microscopic particles down to .3 microns, like dust, pollen, and even smoke.

Then, CirQulate's™ air quality feedback display identifies the air quality of your home in real-time, making your once invisible concerns visible.



Good Air Quality



Moderate Air Quality



Poor Air Quality

Need Some Help?

For more support and information, please visit BISSELLair.com

Warranty

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. If you need additional instructions regarding this warranty or have questions regarding what it may cover, please contact BISSELL Consumer Care by E-mail, telephone, or regular mail as described below.

Limited Two-Year Warranty

Subject to the *EXCEPTIONS AND EXCLUSIONS identified below, upon receipt of the product BISSELL will repair or replace (with new or remanufactured components or products), at BISSELL's option, free of charge from the date of purchase by the original purchaser, for two years any defective or malfunctioning part.

See information below on "If your BISSELL product should require service".

This warranty applies to product used for personal, and not commercial or rental service. This warranty does not apply to fans or routine maintenance components such as filters. Damage or malfunction caused by negligence, abuse, neglect, unauthorized repair, or any other use not in accordance with the User's Guide is not covered.

BISSELL IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE ASSOCIATED WITH THE USE OF THIS PRODUCT. BISSELL'S LIABILITY WILL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

*EXCEPTIONS AND EXCLUSIONS FROM THE TERMS OF THE LIMITED WARRANTY

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ANY OTHER WARRANTIES EITHER ORAL OR WRITTEN. ANY IMPLIED WARRANTIES WHICH MAY ARISE BY OPERATION OF LAW, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE TWO YEAR DURATION FROM THE DATE OF PURCHASE AS DESCRIBED ABOVE.

Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you.

NOTE: Please keep your original sales receipt. It provides proof of date of purchase in the event of a warranty claim.

Service

If your BISSELL product should require service:

If you need information about repairs or replacement parts, or if you have any questions about your warranty, contact BISSELL Consumer Care.

Website:

www.BISSELL.com

Email:

www.BISSELL.com/email-us

Call:

BISSELL Consumer Care

1.800.237.7691

M-F 8am-10pm ET

Sat 9am-8pm ET

Sun 10am-7pm ET

Please do not return this product to the store.

For any questions or concerns, BISSELL is happy to be of service. Contact us directly at 1.800.237.7691.



Registration

Registering is quick, easy and offers you benefits over the lifetime of your product.

You'll Receive:

- **BISSELL Rewards Points**
Automatically earn points for discounts and free shipping on future purchases.
- **Faster Service**
Supplying your information now saves you time should you need to contact us with questions regarding your product.
- **Product Support Reminders and Alerts**
We'll contact you with any important product maintenance reminders and alerts.
- **Special Promotions**
Optional: Register your email to receive notice of offers, contests, cleaning tips and more!

Visit www.BISSELL.com/product-registration

Visit the **BISSELL** website: www.BISSELL.com

When contacting BISSELL, have model number of air purifier available.

Please record your Model Number: _____

Please record your Purchase Date: _____

Note: Please keep your original sales receipt. It provides proof of purchase date in the event of a warranty claim. See the Warranty page for details.

Parts & Supplies

For Parts and Supplies, go to www.BISSELL.com/parts and enter your model number in the search field.

We can't wait to hear from you!

Rate this product and let us (and millions of your closest friends) know what you think!

www.BISSELLair.com



©2018 BISSELL Homecare, Inc.
Grand Rapids, Michigan
All rights reserved. Printed in China
Part Number 161-7362 08/18
Visit our website at: www.BISSELLair.com

please recycle

