


KitchenAid®

24" Under Counter Wine Cellar

MODELS:

KUWR304ESS00 (Stainless, Right Hand)
KUWL304ESS00 (Stainless, Left Hand)

CABINET PARTS



CABINET PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10741576	Use & Care Guide
	W10805711	Energy Guide
2		Cabinet (Not A Service Part)
3	W10204942	Motor & Fan
4	W10205061	Screw
5	W10292475	Thermal Fuse Assembly
6	4344747	Shield, Heat
7	W10797385	Kick Plate
8	W10772863	Cover, Bottom
9	4344763	Leg, Leveling
10	W10778959	Auxiliary Plate
11	W10772866	Main PCB Box
12	W10797389	Frame (Right Hand)
	W10797388	Frame (Left Hand)
13	4344771	Bracket, Grille

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
14	W10804443	Cover, Fan
15	W10780364	Harness, Fan Cover
16	W10775535	Sensor Case
17	W10772916	Temperature Sensor
18	4344826	Screw
19	W10780355	Bolt
20	W10797390	Mount, Kick Plate
21	4344825	Screw
22	4344823	Seal, Brace
23	4344821	Support (Right Hand)
	4344820	Support (Left Hand)
24	W10281496	Cable Clamp
25	W10772870	Harness Extension
26	W10796877	Screw
27	W10204948	Sensor Case Seal
28	W10774183	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
29	W10804444	Plate Cover
30	W10780365	Insulation, Fan Cover
31	W10780357	Spacer, Frame Front
32	W10780356	Frame Front, Bottom
33	W10780349	Screw
34	W10788689	Cover
35	W10721454	Door Switch
36	W10780353	Block Air Circulation
37	W10797391	Lid, Proximity Sensor
38	W10780359	Proximity Sensor
39	W10772869	Cover, Main PCB
40	W10780358	Speaker
41	W10804442	Main PCB
42	W10772858	Defrost Sensor
43	W10788699	Bracket, PCB


SHELF PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10803968	Top Wine Rack Assembly (Right Hinge)
	W10803969	Top Wine Rack Assembly (Left Hinge)
2	W10803971	Wine Rack Assembly, Lower

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10622774	Lens, Light
4	W10797323	LED Light Bar
5	W10319184	Screw
6	W10621514	Liner Bushing

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10805715	Control Panel Assembly
8	W10803984	Trim
9	W10803987	Stainless Trim

DOOR PARTS




DOOR PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	4344796	Screw
2	4344754	Hinge, Top
3	4344760	Washer
4	W10162992	Washer
5	4344753	Bottom Hinge (Right Hinge)
	4344787	Bottom Hinge (Left Hinge)
6	W10780355	Bolt
7	4344798	Spacer, Bottom Hinge
8	W10797377	Screw

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
9	4344801	Screw
10	4344802	Door Stop
11	4344803	Spacer, Door
12	W10622808	Switch Plate
13	4344827	Screw
14	4344804	Spacer, Top Hinge
15	W10624183	Gasket, Door
16	W10803977	Door Assembly (Right Hinge)
	W10803978	Door Assembly (Left Hinge)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
17	W10204866	Screw, Handle
18	W10622815	Plate, Door Handle
19	W10797382	Handle
20	W10797359	Stainless Wrap (Right Hinge)
	W10797360	Stainless Wrap (Left Hinge)
21	W10772910	Nameplate
22	W10772902	Stud, Mounting
23	W10780344	Screw

UNIT PARTS



UNIT PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10316689	Pan, Drain	12	W10778963	Insulation, Rear Cover	24	4344913	Warning Label
2	4344773	Bracket, Defrost Timer	13	W10772886	Screw	25	4344826	Screw
3	W10778965	Overload Relay	14	W10778969	Running Capacitor	26	4344825	Screw
4	4344797	Screw	15	W10796445	Cover, Rear	27	4344832	Screw
5	W10778966	PTC Thermistor	16	W10778967	Cover, Relay	28	4344775	Compressor
6	W10772877	Cabinet Base Plate	17	W10270493	Nut	29	W10772889	Fan Cover, Condenser
7	W10204688	Fan Bushing	18	W10163276	Trap, Drain	30	W10281591	Clamp, Cord
8	4344779	Grommet, Compressor	19	W10204676	Cord, Power	31	W10778971	Clip, Relay Cover
9	W10772873	Bolt	20	4344829	Tie, Cable			REFRIGERANT
10	W10772882	Condenser DC Motor	21	W10163273	Drier			CHARGE
11	W10204674	Air Baffle	22	4344907	Trim, Edge			3.5 oz (R-134)
			23	W10238022	Clip, Bushing			