


KitchenAid®

30" ELECTRIC BUILT-IN WARMING DRAWER

MODELS:

KOWT100ESS00 (Stainless)

CONTROL PANEL AND DRAWER PARTS




CONTROL PANEL AND DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10713340	Guide, Use & Care
	W10064720	Sheet, Tech
	W10713339	Instructions, Installation
2	8273277	Rack, Warming Drawer
3	W10162376	Slide, Vent
4	W10492179	Panel, Front
5	W10164998	Gasket, Drawer

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	9763646	Assembly, Drawer
7	3196537	Screw
8	W10685893	Skin, Drawer
9		Assembly, Handle
	W10541913	Stainless
10		Badge
	W10518672	Grey
11	4455984	Knob, Thermostat
12	W10489562	Light, Indicator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	4456314	Lens, Indicator
14	W10409138	Rail, Pan
15	9763125	Grip, Vent
16	W10035910	Magnet
17	4456861	Spacer, Lens
18	4456862	Clip, Lens Retainer

INTERNAL WARMING DRAWER PARTS



INTERNAL WARMING DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10684523	Wrapper
2	313806	Screw
3	W10188461	Assembly, Slide
4	W10299387	Wall, Cavity (Left)
	9762307	Wall, Cavity (Right)
5	7101P309-60	Screw
6	W10121337	Control
7	W10117362	Gasket, Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	9763126	Fuse, Thermal
9	9763122	Enclosure, Electric
10	9763121	Cover, Enclosure
11	W10117363	Gasket, Enclosure
12	W10546520	Element, Heating
13	3196537	Screw
14	W10118049	Seal, Heating Element
15	W10118113	Seal, Switch

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10118073	Shield, Heat
		FOLLOWING PARTS NOT ILLUSTRATED
	W10129043	Harness, Main
	W10129023	Cord, Power
	W10131847	Sensor, Sealed
	4452601	Relief, Strain
	3400015	Screw, Grounding