SC1500 How To									
Prepare for Use									
1	This is how the machine should look when you enter the room.	2	Disconnect battery and store onboard charger cord.	3	Check the EcoFlex container.				
4	Check recovery tank, ball float and catch cage.	5	Inspect and Install squeegee and hose. Install pad or brush for disc machine.	6	Fill machine with water using front or rear fill port (water should not exceed 130°F).				
	\ 	M	achine Operation	1	\ 				
1	International intervention of the experimental interventintexperimental intervention of the expe	2	Burst of power delivers more water, detergent and pressure to clean stubborn areas.	3	For double scrubbing, swing the squeegee to the right then flip down the squeegee kickstand to hold the back blade off the floor. Flip the kickstand up when done then vacuum solution from the floor.				





SC1500 How To									
Store the Machine (Daily Maintenance)									
1	Empty and recovery tank. Drain water into an open drain	2	Rinse ball float cage. Clean debris catch cage.	3	Rinse and inspect squeegee and blades				
4	Remove and inspect the brush or pad. Rinse pad then set aside to dry.	5	Lift up recovery tank lid for ventilation.	6	Charge the batteries.				
7	Take a clean damp cloth and wipe down exterior of machine.	Maintenance	Use of the second se		 As Needed: Equalize Batteries Annually – inspect carbon brushes on the vacuum motor Annually – inspect the carbon brushes on the brush motor See manual or an Advance Authorized Service Center 				

