




Kitchen - Sync

AIR SWITCH operating button, trim parts only - Brushed durabronz (23kt)

Article number: 10 713 970-28





Kitchen - Sync

AIR SWITCH operating button, trim parts only - Brushed durabrass (23kt)

Article number: 10 713 970-28

Spare parts list

Position	Number of units	Item Number	Spare part	Lead time
1	1	09 28 10 141 90	sleeve	2
2	1	09 27 87 012-28	rosette	20
3	1	09 14 10 507 90	seal	2
4	1	09 21 33 045-28	insert	20
5	1	09 14 10 015 90	seal	2
6	1	09 24 01 030 90	ring	2
7	1	09 14 05 037 90	seal	2
8	1	04 30 01 186 00 90	sleeve	2