





INSTRUCTIONS FOR HANDLE FITS MOEN® TUB/SHOWER

English

Note: Your faucet may not match illustration.

1. Turn water off to faucet.
2. Remove original handle (A) using hex wrench (B) (not included).
3. Remove original handle adapter (C), this is not needed for replacement.
4. Using screwdriver, screw (D) of new handle into cartridge.
5. Place decorative cap (E) over exposed screw on handle.
6. Turn on water to faucet, check for leaks.



POIGNÉE CONVIENT À MOEN® BAIGNOIRE/DOUCHE

Français

Remarque: Votre robinet peut ne pas correspondre à l'illustration.

1. Fermez l'eau vers le robinet.
2. Retirez la manija original (A) con una llave hexagonal (B) (no se incluye).
3. Retirez l'adaptateur de poignée d'origine (C), il n'est pas nécessaire pour le remplacement.
4. À l'aide d'un tournevis, vissez (D) la nouvelle poignée dans la cartouche.
5. Placez le capuchon décoratif (E) sur la vis exposée sur la poignée.
6. Ouvrez l'eau du robinet, vérifiez s'il y a des fuites.

