

IMPORTANT SAFETY INSTRUCTIONS

Wi-Fi Control + USB

MUST BE INSTALLED AND USED ONLY WITH AN APPROVED/CERTIFIED SWIDGET DEVICE. USE WITH ANY OTHER DEVICE IS PROHIBITED AND WILL VOID THE WARRANTY.

WARNING AND CAUTIONS:

- WHILE NOT REQUIRED, IT IS RECOMMENDED TO AVOID ANY RISK OF SHOCK OR DEATH; TURN OFF POWER AT CIRCUIT BREAKER OR FUSE AND TEST THAT THE POWER IS OFF BEFORE INSTALLING OR REMOVING ANY INSERT.
- Not for use to control medical or life support equipment. For INDOOR use only: 32-104F (0-40C).
- Insert can only be installed in one orientation. Rear alignment pins prevent incorrect installation. Do not forcibly install an Insert. When using with a Swidget Outlet, do not use Wi-Fi devices to control electric heaters or any other appliances which may present a hazardous
- condition due to unattended or unintentional or automatic power on control. Double check any external Wi-Fi settings for accuracy before using them.

THAT THE POWER IS OFF BEFORE INSTALLING OR REMOVING INSERT

b. For Inserts being moved, the Insert will power up with the previous location settings
7. Search Google Play or Apple App store for "Swidget".

4. Push Insert into the device cavity until the two side latches engage.

MANUAL OUTLET SWITCHING - Works with connected Insert only

1. Tap Insert button to toggle state of outlet ON or OFF.

2. Follow App based pairing steps for Wi-Fi connection.

- Requires a wireless router and Internet connection for device setup.
- Actual wireless performance in a home depends on the numbers of walls/obstacles between the Insert and wireless router. Use only appropriate Class 2 connectors with interconnecting cables.
- Any output cable connected to the Class 2 output shall be routed away from the receptacle outlet slots or any plug/cord inserted into the receptacle. Class 2 output connections are not intended for supporting products or appliances.

USB Output 5V@2A

For devices with batteries: to reduce the risk of overheating, fire or battery explosion during recharging, consult the manufacturer's charging instructions to check compatibility.

1. TO AVOID SHOCK OR DEATH, IT IS RECOMMENDED TO TURN OFF POWER AT CIRCUIT BREAKER OR FUSE AND TEST

rush miser mino the device cavity driat me who side factiles engage.
Re-enable power to the circuit breaker.
a. FOR FIRST TIME INSTALLATION FROM NEW, THE INSERT LED WILL BLINK WHITE FOR APPROXIMATELY 30 SECONDS TO PREPARE THE DEVICE. INSERT WILL BLINK GREEN WHEN READY FOR NETWORK PAIRING.

This device is to be installed in a Swidget device ONLY.
Orient the Insert to line up with the pins in the device cavity. NOTE: alignment pins will prevent incorrect installation.

DESCRIPTION

FEATUREO

When paired with a Swidget device, the Wi-Fi + USB Insert allows the user remote control and the ability to monitor power used by the device. Users can also charge or power a USB device plugged into the USB charger. The Wi-Fi + USB Insert connects to your home's wireless router via the App (Android and iOS). Once connected the Insert can be monitored and set up for use.

FEATURES:				
•	Remote ON/OFF control via wireless router			
•	Manual ON/OFF control via front panel push b			

- button Independent power monitoring

INSTALLATION:

OPERATION:

- Wi-Fi Compatible USB Power 5VDC@2A (BC1.2)
- INSERT BUTTON ACTIONS

Button Press and Hold	LED State	Action
Momentary Press	-	Toggle Power
9-12 seconds	White	Restart Device
12-15 seconds	Red	Factory Reset
15+ seconds	-	No Action

LED INFORMATION

LED DESCRIPTION	ACTION
Rapidly Blinking White	Initializing
Blinking Green x 2	Ready to pair (Discovery Mode)
Blinking Red x 2	Ready to pair (notify support)
Blinking Blue	Pairing
Blinking Orange x 2	Reconnecting to router
Blinking Orange x 3	Reconnecting to cloud services
Solid Green	Normal Operation (Power state is ON)

PROBLEMS or QUESTIONS:

If you have any problems with or questions about the Swidget device or Insert, contact our tech support team: support@swidget.com

For the most up-to-date product support, accessories, electronic (PDF) format manuals and more, visit www.swidget.com

No user serviceable parts in this unit.

If you have problems with your router, please consult the manufacturer for the appropriate support.

Contains FCC ID: 2AR26-SWIDGETWI100 Contains IC: 24603-SWDTWI10100

FCC COMPLIANCE STATEMENT:

Wi-Fi NETWORK PAIRING/JOINING

Insert is in DISCOVERY MODE.

This device complies with part 15 of the FCC and ISED Canada license-exempt RSS standard(s). Operation is subject to the following two conditions

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

1. Press Insert button and hold for 12-15 seconds until the INSERT LED turns solid RED, then release

LED will begin to rapidly blink WHITE for approximately 30 seconds and then blink GREEN to indicate

FCC NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment complies with FCC and ISED Canada RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20cm between the radiator & your body. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.


- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Important note: To comply with the ISED Canada and FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user's authority to operate the device.





SAVE THESE INSTRUCTIONS

