



operating instructions

Mount the **our**fresh **2.0** in the center of the space (for even fragrance distribution) using mounting tape or anchors/screws (both provided). Recommend 6'-8' above floor to eliminate need for a ladder.



All systems go: blinks GREEN



Battery comes with refill



Replace refill and battery

• Light sensitive – fan runs at regular program setting when there is light and at half program when it is dark (fan does NOT run continuously)



Replace refill: blinks **RED**



Open the cover



Close the cover and recycle refill