MODEL 3-R ACTION-GEAR THE HEADBAND YOU DIAL FOR A PERFECT FIT!





INSTRUCTIONS

ASSEMBLY

To insert into Fibre-Metal W-2F suspension, snap buttons (A) into suspension leg holes (A) and buttons (B) into leg holes (B). Note that legs contain more than one hole. Use lowest holes to obtain greater "depth" in your suspension, or any combination of lower and upper holes to obtain best balance and appearance.

FOR USE WITH WELDING HELMETS OR FACESHIELDS.

Suspension <u>must</u> be reversed in cap shell. Simply remove all eight suspension legs from pockets in cap, reverse direction of shell and reattach legs to matching pockets. Size-adjustment wheel should now be centered beneath cap's peak, which will be worn at back of head.

MAINTENANCE

Wash headgear, including suspension, in warm water with mild household detergent. Allow time for suspension fabric to dry.