

Towel Bar / Towel Ring / Robe Hook / Tissue Holder Installation Instructions

Model No. 24-01, 24-02, 24-03, 24-04, 24-09, 24-12, 24-28

Recommended Installation by a Professional Contractor

1. Using the table below, measure the appropriate distance between post centers. See Figure 1.

Note: Hole locations should be level.

- 18" Single Towel Bar - 18 5/16"
- 18" Double Towel Bar - 18 5/8"
- 24" Single Towel Bar - 24 5/16"
- 30" Single Towel Bar - 30 5/16"
- Tissue Holder - 6 1/4"

2. Drill hole(s) in wall at points marked using the appropriate drill size:

- Wood Screw (#6 x 2") - use: 3/32" Drill
- Toggle Screw (6-32 x 3") - use: 3/8" Drill

3. Dis-assemble ESCUTCHEON (5) and FLANGE (1) from END POST (6). Fasten FLANGE (1) to wall using either WOOD/TOGGLE SCREWS (2). See Figure 2.

4. Place POST (3) into FLANGE (1). Position POST (3) height to 2" from mounting surface. Secure POST (3) into place by tightening SETSCREW (4). See Figure 2.

5. Thread ESCUTCHEON (5) onto POST (3). See Figure 3.

6a. Towel Bars: Assemble towel bar between END POST (6). Place END POST (6) onto POST (3) and secure into place with SETSCREW (4). See Figure 4.

6b. Towel Ring / Robe Hook: Place END POST (6) onto POST (3) and secure into place with SETSCREW (4). See Figure 5.

6c. Tissue Holder: Place END POST (6) onto POST (3) and secure into place with SETSCREW (4). Place HOLDER (7) between END POST (6). See Figure 6.

