



<p>Record your model number below for future reference:</p>	<p>⚠ CAUTION: Risk of personal injury. Do not install where the product might be used as a grab or support bar.</p>	<p>Important Information These products should be located and mounted to a wall stud. While it is possible to mount them to any surface, a stud-mounted product will yield the best results.</p>	<p>Recommended Tissue Holder Location</p>	<p>Verify "X" against the measurements of your product model.</p>	<p>1 For All Installations: Loosen the setscrew and remove the wall plate from the accessory.</p>
<p>2 Single-Post Accessories: Position the wall plate and mark the holes. Verify plumb.</p>	<p>3 Drywall Into Studs: Drill 1/8" holes. Secure the wall plate(s).</p>	<p>Between Studs Or Into Tile: Drill 5/16" holes. Insert the anchors. Secure the wall plate(s).</p>	<p>4 For All Accessories: Position the accessory onto the wall plate(s). Tighten the setscrew(s).</p>		

Questions? Problems? For additional assistance, please contact KALLISTA's Customer Service Department at 1-888-4-KALLISTA (1-888-452-5547) or kallista.com.