



# J-Fill® Portable

## Dispensing System

Portable, hand held dispenser that dispenses a wide variety of cleaners and disinfectants for any job.

### Features & Benefits

- Fills auto scrubbers, buckets and bottles easily, with the push of a button
- Dispenser quick-connects to water supply hose and has Air Gap backflow prevention
- Portable with single hand operation and hands-free bucket filling option
- Dispenses any of the J-Fill® line of chemicals while consistently delivering accurate dilutions anywhere you need them
- Lockable dispensing head holds cartridge firmly into place
- Comes with water hose and quick connects for easy hook-up

### Applications

- Attach to J-Fill bottle to provide portable dilution control
- Use as dispensers in Food Service, Lodging, Health Care, Education, Government, Retail and BSC





### Use Overview

J-Fill® Portable Dispensing System consistently delivers accurate dilutions anywhere you need them. Simply select the product you desire, attach the Spill-Tite™/MC cartridge, hook up to a water supply and press the trigger. Dispenses into bottles, buckets and auto scrubbers. Can be used with the full J-Fill® chemical offering.



Fills automatic scrubbers, buckets and bottles quickly and easily



Water supply hose quick-connects to almost any water source

### Dispensing Product Instructions

- **Attach J-Fill® Portable Dispensing System** to any J-Fill® container and lock into place.
- Connect dispenser using quick-connect to water supply hose.
- Turn on the water supply.
- **For Filling Spray Bottles:** Insert the nozzle into spray bottle and fully depress trigger. Ensure discharge tube is as far down as possible to limit foaming.
- **For Filling Buckets or Auto Scrubbers:** Insert the nozzle in the receptacle and press the trigger. If desired, the J-Fill® dispenser can be hung on the lip of the receptacle.
- **Optional – Lockable Trigger Button for Hands-Free Filling:** To lock, press down, push in the trigger lock button. To release, press down on trigger.
- If desired, J-Fill® dispenser can be rinsed between cartridge changes. Simply remove the cartridge and hold the unit over a sink or drain. Press the trigger for 5–10 seconds to flush dispensing head.

Technical data	J-Fill® Portable
Unit Dimensions	Weight: 3 lbs. (11.4 kg)
Water Supply Hose	5 ft. (1.5 m)
Operating Range Requirements	<b>Water Pressure:</b> 25–85 psi (170–580 KPA)
	<b>Water Flow:</b> 2.5 gal./min. (9.46 L /min.)
	<b>Water Temperature:</b> 40–120° F (4–49° C)

ASSE 1055-B backflow prevention requirements.

Product	Description	Product code
J-Fill® Portable	J-Fill® Dispensing System	D5615573 

### Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at [www.diversey.com](http://www.diversey.com) or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.