

Tub/Shower Module TS2-2954 Alcove Style (Flanged) Bath Module TO-2954



These guidelines are recommended by MAAX Aker for the proper installation of their product. A careful review of these procedures (and any referenced publications) before starting is important in avoiding unnecessary problems resulting in an improper assembly or installation.

NOTE: All drawings in this publication are typical, and may appear different than the actual items being installed. In addition, optional items may be shown on the units which may not have been ordered on the unit being installed.

SPECIAL NOTES TO INSTALLER

★ It is the sole responsibility of the installer to determine, prior to installation, the requirements necessary for compliance with all codes involving the unit or the installation!

★ All paperwork packaged with the unit and any associated options or accessories should be saved and presented to the home owner upon completion of the installation! ★ All published unit dimensions are for reference only. Any critical dimensions required for installation should be taken directly from the unit being installed!

★ Any independent changes made to the unit (or options and accessories supplied with the unit) beyond those required for normal installation can void all warranties! (*Refer to warranties for further information*)

Inspection Guidelines

Carefully check the unit upon receipt. Notify your supplier immediately if any questions or problems are encountered during this process.

DO NOT INSTALL ANY UNIT WITHOUT FIRST ADDRESSING QUESTIONS WHICH ARISE DURING THE INSPECTION!

Basic Module Check

 Check unit drain for match to bathroom drain location.
 Check for unit surface damage. ✓ Check unit color for coordination to other bathroom fixtures.

ON TS2-2954 MODEL ONLY Check wall section and base for color match.

Check grab bar for finish ordered.

Framing Requirements

Due to individual site variations, exact guidelines for every situation cannot be supplied. The recommended framing and dimensional requirements shown are for a typical application and may vary, depending on site requirements.

The dimensions shown in Figure 1 are from the surfaces where the unit will be attached. This surface can be bare studding, dry wall or other suitable underlayment material. It is important that the floor and all framing be square and level. Framing should be done using accepted materials and construction techniques, in accordance with all applicable codes.





Model	Unit Surface	Sump Bottom Dim. (W x L)	Dry Unit Weight	Avg. Oper. Volume	Max. Sump Capacity	Base Area	Floor Loading
TO-2954	Gelcoat	18 x 38 in.	75 lb.	N/A	33 gal.	N/A	N/A
TS2-2954	Gelcoat	18 x 38 in.	144 lb.	N/A	33 gal.	N/A	N/A



Tub Installation Procedure

NOTE: The TS2-2954 is designed to be installed in two sections from the front. However, it may also be reassembled using bolts (not supplied) and installed like a one-piece unit.

With the tub section (without the walls for the TS2-2954) positioned in the framed area, several details must be checked prior to securing the unit in place. (Figures 2a & 2b)

 \checkmark Confirm unit apron is resting flush on the floor.

✓ Confirm drain position.

 \checkmark Confirm the unit is level along each side and each end.

 \checkmark Confirm the unit is square in the framed area.

The use of shim or filler material behind the nailing flange at each framing member may be required to maintain the unit in the proper position.

After the tub section is confirmed level and square within the alcove, drill a 1/8 inch hole through the nailing flange at each framing member and every 8 inches along the front nailing flanges. Secure the unit in place across the back wall first, followed by the flanges at each end and along the front flanges, using 1-1/4 inch long (large headed) nails or other appropriate fasteners. Continuously check to confirm the unit remains square within the alcove as it is being secured. (Figures 3a & 3b)

WARNING! THE UNIT BOTTOM SHOULD BE CLEAR OF POTENTIALLY DAMAGING DEBRIS AND THE SURFACE PROTECTED BEFORE STEPPING INSIDE.

CAUTION: It is advisable to protect the unit surface with a thin plywood or cardboard shield while fastening the flange to the framing.



Wall-to-Base Application TS2-2954 Only

Prior to placing the wall surround on the installed tub section, wipe off the flange on the bottom of the wall surround and the ledge of the tub where the wall will rest to ensure the surface is clean and dry for the silicone. Starting at the front edge of the tub ledge, apply a continuous 1/8" bead of silicone along the entire length of the ledge surrounding three sides of the tub.

FORDENUINIT IN STIBULAALIADIKON

NOTE: Silicone sealant must be supplied by the unit installer.

Carefully place the wall surround on the tub ledge, adjusting the wall at each front corner and along the inside surfaces to form a tight, clean and even seam. (Figure 4a)

After aligning the wall surround, drill a 1/8 inch hole through the nailing flange at each framing member and every 8 inches along the front nailing flanges. Secure the wall surround, using 1-1/4" long large headed nails or other appropriate fasteners, starting at the lower front wall flange nearest the seam and continuing up the flange at each tub end. Continuously check to confirm the wall remains plumb along the inside front corner. (This is critical for the proper installation of an enclosure.) The use of shim or filler material behind the nailing flange may be required to maintain the wall in proper position. (Figure 4b)

CAUTION: It is advisable to protect the unit surface with a thin plywood or cardboard shield while fastening the flange to the framing.

Proceed by fastening the top wall flange to the framing members at each tub end, followed by the back wall flange. Special care should be used when securing the top flanges to avoid pulling the wall surround/tub seam open. Continuously check to ensure the seam is tight during this procedure. If required, place shim or filler material behind the top nailing flange to avoid opening the seam.





WARNING! THE UNIT BOTTOM SHOULD BE CLEAR OF POTENTIALLY DAMAGING DEBRIS AND THE SURFACE PROTECTED BEFORE STEPPING INSIDE.

REMOVE ANY EXCESS SILICONE FROM THE UNIT SURFACE BEFORE IT CURES.

Water Supply and Drain Connections

Refer to, and follow, the assembly and installation instructions provided with the supply valves and drain system. Carefully check all fittings and connections for leaks.

Finishing Guidelines

Furring strips or filler material may be required over the framing to ensure the underlayment will lie flush over the nailing flanges. A water resistant underlayment is recommended on areas surrounding the unit. Stop the underlayment 1/16 to 1/8 inch from the unit surface, and fill the space with a continuous bead of waterproof sealant.

Carefully fasten the underlayment near the unit to avoid damaging the unit surface. Seal the seams and edges of the underlayment, as required, and install the finish material to specifications. (Figure 5)

Unit Surface Care

WARNING! NEVER USE ABRASIVE MATERIALS. NOR ABRASIVE CLEANERS ON THE UNIT SURFACE!

EXTREME CAUTION is urged regarding the use of any cleaner, acid or solvent on the unit surface.

READ, AND FOLLOW ALL PACKAGE LABELS AND INSTRUCTIONS!

Through routine use, the unit surface can collect residues from soap, bath additives and natural body oils. Additional deposits can also collect from minerals or particles found in the water. After each use, wipe the excess water



from the unit. This practice will reduce the build-up of deposits and help maintain the natural unit lustre. Following a thorough surface cleaning, an application of quality automotive wax will help reduce major accumulations. The actual schedule for cleaning, and waxing, will depend on unit usage and water quality.

WARNING! AVOID APPLYING WAX TO THE UNIT BOTTOM!

◆ <u>Routine Cleaning:</u> Mild, non-abrasive cleaner specifically formulated for gelcoat and acrylic surfaces recommended. (*Rinse surface thoroughly*)

◆ <u>Heavy Soap Deposits:</u> Liquid ammonia household cleaner, applied full strength. (*Rinse surface thoroughly*)

• <u>Stubborn Stains</u>: Liquid household cleaner or hydrogen peroxide, applied full strength. Place a saturated clean rag directly on stain and let stand several hours. (*Rinse surface thoroughly*)

For extreme cases, buff area with white automotive polishing compound until stain disappears, and apply a quality automotive wax to surface. ◆ <u>Hard Water Scales:</u> Liquid scale remover or white vinegar, applied full strength. (*Rinse surface thoroughly*)

◆ <u>Mold/Mildew:</u> Liquid mildew remover or baking soda and water paste. (Apply paste and allow to fizz several minutes.) (*Rinse surface thoroughly*)

◆ <u>Construction Adhesive</u>: Soften adhesive with hand held dryer and peel off adhesive. (*Caution is advised when using any electrical device near water.*)

For stubborn cases, apply rubbing alcohol or nail polish remover, full strength, to adhesive. (*Rinse surface thoroughly*)

WARNING! BATH MATS OR OTHER ITEMS WHICH ARE HELD IN PLACE USING SUCTION AGAINST THE UNIT SURFACE MUST BE REMOVED FROM THE FLOOR OF THE UNIT AFTER EACH USE.

OVER A PROLONGED PERIOD, FAILURE TO REMOVE THESE TYPES OF ITEMS FROM THE BOTTOM OF THE UNIT CAN RESULT IN SURFACE DAMAGE.



MAAX Aker as the manufacturer of Bath, Tub/Shower, Shower and Whirlpool Equipped Modules, reserves the right without prior notice to:

- a. Modify the design and manufacture of its existing products or product lines without incurring any obligation to make like modifications to products previously manufactured.
- b. Add new products, product lines and/or colors and options.
- c. Discontinue existing products, product lines and/or colors and options.

Any claims, statements or contracts made regarding materials, manufacturing methods, duration and/or obligations involving MAAX Aker other than those stated in the MAAX Aker written Limited Warranty are disclaimed. Review the terms and conditions of the Limited Warranty.

Code compliance for the basic unit structure and construction is monitored by recognized groups using accepted testing and inspection procedures.

ANSI Z 124.1 - 1995 American National Standard for Plastic Bathtub Units

MAAX Marion 4601 Eighth Avenue Marion, IA 52302

MAAX Martinsburg 718 Mid-Atlantic Parkway Martinsburg, WV 25401

MAAX Plymouth 2121 Walter Glaub Dr. Plymouth, IN 46563

MAAX Valdosta 1625 James P. Rodgers Road Valdosta, GA 31601

GELCOATED FIBERGLASS AND VACUUM FORMED ACRYLIC LIMITED WARRANTY

MAAX Aker extends to the original purchaser and subsequent consumer a limited warranty on MAAX Aker Gelcoated Fiberglass and Vacuum Formed Acrylic modules (herein called "unit") against defects in materials and/or workmanship, which results in a significantly altered appearance or affects the performance of the unit for its intended purpose during the time period stated from date of purchase.

During this time period, MAAX Aker will, at its discretion (following inspection and verification of the claimed defect by an authorized company representative) either repair and/or refinish the unit or supply a replacement unit of comparable size and color without charge, but excluding any costs associated with the removal of and/or reinstallation of the unit. All MAAX Aker authorized and installed options and accessories are addressed under a separate warranty coverage program titled: OPTIONS AND ACCESSORIES LIMITED WARRANTY.

THIS WARRANTY DOES NOT COVER DEFECTS RESULTING FROM: (a) improper unit installation, the surrounding structure or plumbing connections beyond the recommendations supplied by MAAX Aker within the scope of applicable codes and ordinances; or

(b) accident, abuse, misuse, negligence, fire, flood, or acts of God; or
(c) unreasonable use, including any use beyond that intended for the unit and/ or failure to follow the Care and Maintenance Instructions for the unit; or
(d) any unauthorized alteration or modification to the unit beyond those required for normal installation, the addition of auxiliary powered devices or systems including but not limited to those which generate light, heat, or steam, or any other deviation to the unit not specifically designed for the unit, nor authorized in writing or installed by MAAX Aker; or

(e) removal of unit from the initial installation site; or

(f) the additions of enclosures, handicap accessories, grab bars, and/or other appliances and fittings (including installation technique) not specifically designed for the unit, nor authorized in writing or installed by MAAX Aker.

REPAIR, REFINISHING, OR THE SUPPLY OF A REPLACEMENT UNIT UNDER THIS WARRANTY SHALL BE THE EXCLUSIVE REMEDY. MAAX AKER SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING ANY DAM-AGE TO THE BUILDING, ITS CONTENTS OR OCCUPANTS, OR FOR BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY. ANY IMPLIED WARRANTY REGARDING UNIT FITNESS FOR A PARTICULAR PURPOSE IS LIMITED IN DURATION TO THE TERMS OF THIS WARRANTY.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on the duration of an implied warranty. Therefore, the above exclusions and/or limitations may not apply.

THIS WARRANTY PROVIDES SPECIFIC LEGAL RIGHTS, WHICH CAN VARY FROM STATE TO STATE.