

- 1x ScentBeat Diffuser
 1x ScentBeat Manual
- 1x SafeLock Key
- 1x Wall Mount Bracket
- 1 x Power Plug
 - screws power plug mounting bracket atomizer nozzle SafeLock key

 1x Wall Mounting Hardware (3 wall

anchors + 3 screws)

• 1x Atomizer Nozzle



- Use the SafeLock key to unlock and open the door (lock is located on the right side of the unit)
- 2. Unscrew the atomizer nozzle from the top of the diffuser, open door and pull the atomizer head from inside the diffuser to remove
- Insert the straw into a bottle of ScentBridge fragrance oil and tighten atomizer head fully.
 *Please note that using another oil not provided by ScentBridge will void the warranty
- 4. Reinstall the atomizer head with attached fragrance bottle back into the diffuser
- 5. Screw on the atomizer nozzle
- 6. Plug in the diffuser using the provided power plug
- 7. Lock the diffuser door using the SafeLock key
- 8. Adjust settings as needed in ScentSetter App



其 TROUBLESHOOTING

Before reaching out to our technical personnel, please take a look at the following possible solutions. If you need further assistance, please email us at service@scentbridge.com.

Diffuser Not Connecting to Smart Device:

- Close the ScentSetter app
- Turn off Bluetooth on your smart device, then unplug ScentBeat diffuser
- Turn the smart device's Bluetooth back on, then plug ScentBeat diffuser back in
- Listen for the diffuser to beep, then open the ScentScetter app and select the diffuser

Weak or No Diffusion:

- Diffuser will not run when not scheduled, ensure the schedule is correct in the ScentSetter app
- The air pump may be damaged, replace if still under warranty
- Check to ensure the straw is not loose

Oil Leaking or Spraying:

- Ensure the atomizer head is tightly screwed in
- The gasket in the atomizer head may be damaged or loose
- The atomizer head is damaged, contact support if still under warranty

user manual **ScentBeat**

WIDE AREA FRAGRANCE DIFFUSER

TABLETOP OR WALL MOUNT USE BLUETOOTH APP CONTROL ANTI-TAMPER 'SAFELOCK'






 833 723 6835 - OPTION 1
 SERVICE@SCENTBRIDGE.COM
 SHOP.SCENTBRIDGE.COM
 20 INDUSTRIAL DRIVE E, SOUTH DEERFIELD MA 0 1373

APP GUIDE

Search the Google Play Store (Android) or the App Store (iOS) for "ScentSetter"

TO LOG IN

- Ensure Bluetooth is enabled on your smart device
- Open the app and tap the diffuser name (default is a string of letters and numbers but can be renamed later)
- Enter the default password "8888" and tap "Login"
- The system will beep when connected



Optional: To estimate remaining days, it is recommended to let the diffuser work for 10 days. Remove the bottle and measure remaining oil in ml. Tap Calibrate, enter ml of remaining oil and tap Confirm then Save to update



Slid

APP GUIDE CONTINUED

TO EDIT WORKING PERIODS (add up to 5)

	← Working period setting		etting	Save
	Start working	time s	Stop worki	ng time
		8 9	17 18	58 59
e up + down to adjust start + stop times	07 0	0	19	00
_	08 0		20 21	01 02
Select working days	Repeat Thur	Mon Tue	Sat	Sun
l				
Select Grade (1-20) or Custom Work Time	√ Grade		-	6 +
	√ GradeCustom		-	6 +
		e(S)	- Stop Time	-
	Custom		- Stop Time 298	-
	Custom Work Time		298 299	-
	Custom Work Time 13 14		298 299 300	
	Custom Work Time		298 299	-

TO CHANGE PASSWORD

Tap "About" Tap "Change Password" Enter new password and tap "Confirm"



OPTIONAL WALL MOUNTING

- 1. Line up the mounting bracket where you would like to install the diffuser on the wall
- 2. Drill holes in the wall. Insert the wall anchors, then the screws, then tighten the bracket to the wall
- 3. Hang the diffuser on the bracket



CAUTION / WARNING

- 1. Keep the machine upright. Tilting or laying flat will cause the oil to over flow
- 2. Remove fragrance bottle before moving diffuser to avoid spills
- 3. Do not disassemble or attempt to repair the diffuser. If any failure happens to the machine, please see the Troubleshooting section
- 4. The touchscreen buttons become inactive after 1 minute of inactivity
- 5. If the display freezes, please reset to default settings. (Press and hold the ENT button until it beeps)



SPECIFICATIONS

Bottle Capacity: Input Voltage: Power: Coverage: Material: Weight: Color:

850 ml DC 12V 9W up to 5000 sq.ft. Plastic 2.13kgs/G.W.: 2.8kgs White / Black



The machine should be cleaned when:

- You are switching to a different oil.
- The atomization volume becomes weak.

Cleaning steps:

- Unscrew and remove the atomizer head
- Use a container filled with isopropyl alcohol to soak the atomizer head for 5-10 minutes
- Air dry the atomizer head