

INSTALLATION INSTRUCTIONS

Apollo Valves


THE APOLLO MODEL PR & PRLF (PRESSURE REDUCING VALVE) IS TO BE INSTALLED IN THE WATER LINE WITH THE ARROW ON THE VALVE POINTING IN THE DIRECTION OF THE FLOW. THIS VALVE IS FACTORY SET AT 50 PSI. UNLESS OTHERWISE SPECIFIED BY CUSTOMER. THE PRIMARY PURPOSE OF A PRESSURE REDUCING VALVE IS TO REDUCE THE WATER PRESSURE COMING IN FROM THE CITY MAIN DOWN TO A MORE FUNCTIONAL LINE PRESSURE IN THE HOME. REDUCED PRESSURE WILL RESULT IN A SAVINGS TO THE USER ON THEIR WATER CONSUMPTION. THE MODEL PR COMES STANDARD WITH A THERMAL EXPANSION BY-PASS FEATURE WHICH DISSIPATES THE EXPANDED DOWNSTREAM PRESSURE BACK TO THE SERVICE MAIN.

! CALIFORNIA PROP 65: WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

FOR NON-LEAD FREE VALVES: It is illegal to use this product in the United States for potable water services (water intended for human consumption).

FOR LEAD FREE VALVES: This product complies with U.S. Safe Drinking Water Act (SDWA). Suitable for potable water applications intended for human consumption.

REPAIR KITS FOR 36 SERIES PRESSURE REDUCING VALVES				REPAIR KITS FOR 36LF SERIES PRESSURE REDUCING VALVES			
APOLLO SERIES	SIZE	CARTRIDGE ASSY.	DIAPHRAGM	APOLLO SERIES	SIZE	CARTRIDGE ASSY.	DIAPHRAGM
36-03, 36-203, 36-303	1/2	W6462-06	D2419-00	36LF-103, 36LF-203, 36LF-303	1/2	W960006	D2419-00
36-104, 36-204, 36-304	3/4	W6462-06	D2419-00	36LF-104, 36LF-204, 36LF-304	3/4	W960006	D2419-00
36-105, 36-205, 36-305	1	W6474-06	D4842-00	36LF-105, 36LF-205, 36LF-305	1	W960106	D4842-00
36-106, 36-206, 36-306	1 1/4	W6712-06	D2558-00	36LF-106, 36LF-206, 36LF-306	1 1/4	W960206	D2558-00
36-107, 36-207, 36-307	1 1/2	W6712-06	D2558-00	36LF-107, 36LF-207, 36LF-307	1 1/2	W960206	D2558-00
36-108, 36-208, 36-308	2	W6714-06	D2559-00	36LF-108, 36LF-208, 36LF-308	2	W954106	D2559-00



SIDE A

MAINTENANCE INSTRUCTIONS

ALL STANDARD VALVES ARE FACTORY SET AT 50 PSI. IN ORDER TO RAISE OR LOWER THE PRESSURE SETTING, LOOSEN LOCK NUT AND TURN ADJUSTMENT SCREW CLOCKWISE TO RAISE PRESSURE OR COUNTERCLOCKWISE TO LOWER PRESSURE, RETIGHTEN LOCK NUT.


TO REPLACE CARTRIDGE

1. SHUT OFF WATER SERVICE TO DWELLING AT MAIN.
2. OPEN A FAUCET TO RELIEVE PRESSURE, LEAVE OPEN.
3. BACK OFF LOCK NUT AND ADJUSTING SCREW.
4. LOOSEN BELL HOUSING, REMOVE SPRING, DISC, AND FRICTION WASHER.
5. REMOVE BOLT, PRESSURE PLATE, AND DIAPHRAGM.
6. REMOVE CARTRIDGE ASSEMBLY.
7. REMOVE SCREEN, CLEAN OFF ANY GRIT, EXAMINE BODY FOR DEBRIS AND FLUSH OUT.

TO RE-ASSEMBLE

1. SCREW IN NEW CARTRIDGE ASSEMBLY AND TIGHTEN.
2. REPLACE DIAPHRAGM, PRESSURE PLATE AND BOLT.
3. REPLACE SPRING, DISC, FRICTION WASHER, AND BELL HOUSING, TIGHTEN.
4. TURN IN ADJUSTING SCREW TO OLD SETTING, TIGHTEN LOCK NUT.
5. CHECK ALL FITTINGS AND TURN WATER BACK ON.
6. LET WATER RUN A FEW MOMENTS TO FLUSH THE SYSTEM OF AIR.
7. TO ADJUST PRESSURE ON REGULATOR TO DESIRED SETTING, TURN **CLOCKWISE TO RAISE PRESSURE OR COUNTERCLOCKWISE TO LOWER PRESSURE.**

I-4222-00



SIDE B