

## Preventive Maintenance

**Water Coil Maintenance** - (Direct ground water applications only) If the system is installed in an area with a known high mineral content (125 P.P.M. or greater) in the water, it is best to establish a periodic maintenance schedule with the owner so the coil can be checked regularly. Consult the well water applications section of this manual for a more detailed water coil material selection. Should periodic coil cleaning be necessary, use standard coil cleaning procedures, which are compatible with the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling. Therefore, 1.5 gpm per ton [1.6 l/m per kW] is recommended as a minimum flow. Minimum flow rate for entering water temperatures below 50°F [10°C] is 2.0 gpm per ton [2.2 l/m per kW].

**Water Coil Maintenance** - (All other water loop applications) Generally water coil maintenance is not needed for closed loop systems. However, if the piping is known to have high dirt or debris content, it is best to establish a periodic maintenance schedule with the owner so the water coil can be checked regularly. Dirty installations are typically the result of deterioration of iron or galvanized piping or components in the system. Open cooling towers requiring heavy chemical treatment and mineral buildup through water use can also contribute to higher maintenance. Should periodic coil cleaning be necessary, use standard coil cleaning procedures, which are compatible with both the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling. However, flow rates over 3 gpm per ton (3.9 l/m per kW) can produce water (or debris) velocities that can erode the heat exchanger wall and ultimately produce leaks.

**Hot Water Generator Coils** - See water coil maintenance for ground water units. If the potable water is hard or not chemically softened, the high temperatures of the desuperheater will tend to scale even quicker than the water coil and may need more frequent inspections. In areas with extremely hard water, a HWG is not recommended.

**Filters** - Filters must be clean to obtain maximum performance. Filters should be inspected every month under normal operating conditions and be replaced when necessary. Units should never be operated without a filter.

Washable, high efficiency, electrostatic filters, when dirty, can exhibit a very high pressure drop for the fan motor and reduce air flow, resulting in poor performance. It is especially important to provide consistent washing of

these filters (in the opposite direction of the normal air flow) once per month using a high pressure wash similar to those found at self-serve car washes.

**Condensate Drain** - In areas where airborne bacteria may produce a "slimy" substance in the drain pan, it may be necessary to treat the drain pan chemically with an algicide approximately every three months to minimize the problem. The condensate pan may also need to be cleaned periodically to ensure indoor air quality. The condensate drain can pick up lint and dirt, especially with dirty filters. Inspect the drain twice a year to avoid the possibility of plugging and eventual overflow.

**Compressor** - Conduct annual amperage checks to ensure that amp draw is no more than 10% greater than indicated on the serial plate data.

**Fan Motors** - All units have lubricated fan motors. Fan motors should never be lubricated unless obvious, dry operation is suspected. Periodic maintenance oiling is not recommended, as it will result in dirt accumulating in the excess oil and cause eventual motor failure. Conduct annual dry operation check and amperage check to ensure amp draw is no more than 10% greater than indicated on serial plate data.

**Air Coil** - The air coil must be clean to obtain maximum performance. Check once a year under normal operating conditions and, if dirty, brush or vacuum clean. Care must be taken not to damage the aluminum fins while cleaning. When the heat pump has experienced less than 100 operational hours and the coil has not had sufficient time to be "seasoned", it is necessary to clean the coil with a mild surfactant such as Calgon to remove the oils left by manufacturing processes and enable the condensate to properly "sheet" off of the coil. CAUTION: Fin edges are sharp.

**Cabinet** - Do not allow water to stay in contact with the cabinet for long periods of time to prevent corrosion of the cabinet sheet metal. Generally, vertical cabinets are set up from the floor a few inches [7 - 8 cm] to prevent water from entering the cabinet. The cabinet can be cleaned using a mild detergent.

**Refrigerant System** - To maintain sealed circuit integrity, do not install service gauges unless unit operation appears abnormal. Reference the operating charts for pressures and temperatures. Verify that air and water flow rates are at proper levels before servicing the refrigerant circuit.

# CLIMATEMASTER WATER-SOURCE HEAT PUMPS

## Tranquility® 30 (TT) Series

Rev.: October 7, 2016

### Functional Troubleshooting

Fault	Htg	Clg	Possible Cause	Solution				
Main power problems	X	X	Green Status LED Off	Check line voltage circuit breaker and disconnect. Check for line voltage between L1 and L2 on the contactor. Check for 24VAC between R and C on CXM/DXM' Check primary/secondary voltage on transformer.				
			HP Fault Code 2	X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting. Check water flow adjust to proper flow rate.		
				X	Water Temperature out of range in cooling	Bring water temp within design parameters. Check for dirty air filter and clean or replace.		
			High Pressure	X		Reduced or no air flow in heating	Check fan motor operation and airflow restrictions. Dirty Air Coil- construction dust etc. Too high of external static. Check static vs blower table.	
X	Air temperature out of range in heating	Bring return air temp within design parameters.						
X	Overcharged with refrigerant	Check superheat/subcooling vs typical operating condition table.						
X	Bad HP Switch	Check switch continuity and operation. Replace.						
LP/LOC Fault Code 3	X	X		Insufficient charge	Check for refrigerant leaks			
Low Pressure / Loss of Charge	X		Compressor pump down at start-up	Check charge and start-up water flow.				
			LT1 Fault Code 4	X		Reduced or no water flow in heating	Check pump operation or water valve operation/setting. Plugged strainer or filter. Clean or replace. Check water flow adjust to proper flow rate.	
Water coil low temperature limit	X	Inadequate antifreeze level	Check antifreeze density with hydrometer.					
	X	Improper temperature limit setting (30°F vs 10°F [-1°C vs -2°C])	Clip JW3 jumper for antifreeze (10°F [-12°C]) use.					
	X	Water Temperature out of range	Bring water temp within design parameters.					
	X	Bad thermistor	Check temp and impedance correlation per chart Check for dirty air filter and clean or replace.					
LT2 Fault Code 5		X	Reduced or no air flow in cooling	Check fan motor operation and airflow restrictions. Too high of external static. Check static vs blower table. Too much cold vent air? Bring entering air temp within design parameters.				
			X	Air Temperature out of range	Normal airside applications will require 30°F [-1°C] only.			
			X	Improper temperature limit setting (30°F vs 10°F [-1°C vs -2°C])	Normal airside applications will require 30°F [-1°C] only.			
			X	Bad thermistor	Check temp and impedance correlation per chart.			
			X	Blocked drain	Check for blockage and clean drain.			
Condensate Fault Code 6		X	Improper trap	Check trap dimensions and location ahead of vent. Check for piping slope away from unit. Check slope of unit toward outlet. Poor venting. Check vent location.				
			X	X	Poor drainage	Check for moisture shorting to air coil.		
					Moisture on sensor	Check for moisture shorting to air coil.		
			X	X	Plugged air filter	Replace air filter.		
			X	X	Restricted Return Air Flow	Find and eliminate restriction. Increase return duct and/or grille size.		
			Over/Under Voltage Code 7 (Auto resetting)	X	X	Under Voltage	Check power supply and 24VAC voltage before and during operation. Check power supply wire size. Check compressor starting. Need hard start kit? Check 24VAC and unit transformer tap for correct power supply voltage.	
X	X	Over Voltage				Check power supply voltage and 24VAC before and during operation. Check 24VAC and unit transformer tap for correct power supply voltage.		
		Unit Performance Sentinel Code 8				X	Heating mode LT2>125°F [52°C]	Check for poor air flow or overcharged unit.
		X				Cooling Mode LT1>125°F [52°C] OR LT2<40°F [4°C]	Check for poor water flow, or air flow.	
Swapped Thermistor Code 9	X	X	LT1 and LT2 swapped	Reverse position of thermistors				
No Fault Code Shown	X	X	No compressor operation	See "Only Fan Operates".				
			Compressor overload	Check and replace if necessary.				
			Control board	Reset power and check operation.				
Unit Short Cycles	X	X	Dirty air filter	Check and clean air filter.				
			Unit in "test mode"	Reset power or wait 20 minutes for auto exit.				
			Unit selection	Unit may be oversized for space. Check sizing for actual load of space.				
			Compressor overload	Check and replace if necessary				
			Thermostat position	Ensure thermostat set for heating or cooling operation.				
Only Fan Runs	X	X	Unit locked out	Check for lockout codes. Reset power.				
			Compressor Overload	Check compressor overload. Replace if necessary.				
			Thermostat wiring	Check thermostat wiring at heat pump. Jumper Y and R for compressor operation in test mode.				
			Thermostat wiring	Check G wiring at heat pump. Jumper G and R for fan operation				
Only Compressor Runs	X	X	Fan motor relay	Jumper G and R for fan operation. Check for Line voltage across BR contacts.				
			X	X	Fan motor	Check fan power enable relay operation (if present). Check for line voltage at motor. Check capacitor.		
			X	X	Thermostat wiring	Check thermostat wiring at heat pump. Jumper Y and R for compressor operation in test mode		
			Unit Doesn't Operate in Cooling		X	Reversing valve	Set for cooling demand and check 24VAC on RV coil and at CXM/DXM board. If RV is stuck, run high pressure up by reducing water flow and while operating engage and disengage RV coil voltage to push valve.	
X	Thermostat setup	Check for 'O' RV setup not 'B'.						
X	Thermostat wiring	Check O wiring at heat pump. Jumper O and R for RV coil 'click'.						
X	Thermostat wiring	Put thermostat in cooling mode. Check 24 VAC on O (check between C and O); check for 24 VAC on W (check between W and C). There should be voltage on O, but not on W. If voltage is present on W, thermostat may be bad or wired incorrectly.						

Performance Troubleshooting

Performance Troubleshooting	Htg	Clg	Possible Cause	Solution	
Insufficient capacity/ Not cooling or heating	X	X	Dirty filter	Replace or clean.	
	X		Reduced or no air flow in heating	Check for dirty air filter and clean or replace.	
				Check fan motor operation and airflow restrictions.	
				Too high of external static. Check static vs. blower table.	
		X	Reduced or no air flow in cooling	Check for dirty air filter and clean or replace.	
				Check fan motor operation and airflow restrictions.	
				Too high of external static. Check static vs. blower table.	
		X	X	Leaky duct work	Check supply and return air temperatures at the unit and at distant duct registers if significantly different, duct leaks are present.
		X	X	Low refrigerant charge	Check superheat and subcooling per chart.
		X	X	Restricted metering device	Check superheat and subcooling per chart. Replace.
			X	Defective reversing valve	Perform RV touch test.
		X	X	Thermostat improperly located	Check location and for air drafts behind stat.
	X	X	Unit undersized	Recheck loads & sizing. Check sensible clg. load and heat pump capacity.	
	X	X	Scaling in water heat exchanger	Perform scaling check and clean if necessary.	
	X	X	Inlet water too hot or too cold	Check load, loop sizing, loop backfill, ground moisture.	
High Head Pressure	X		Reduced or no air flow in heating	Check for dirty air filter and clean or replace.	
				Check fan motor operation and air flow restrictions.	
				Too high of external static. Check static vs. blower table.	
			X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting.
				Check water flow. Adjust to proper flow rate.	
		X		Inlet water too hot	Check load, loop sizing, loop backfill, ground moisture.
		X		Air temperature out of range in heating	Bring return air temperature within design parameters.
		X	X	Scaling in water heat exchanger	Perform scaling check and clean if necessary.
Low Suction Pressure			Reduced water flow in heating.	Check pump operation or water valve operation/setting.	
				Plugged strainer or filter. Clean or replace.	
				Check water flow. Adjust to proper flow rate.	
			X	Water temperature out of range.	Bring water temperature within design parameters.
			X	Reduced air flow in cooling.	Check for dirty air filter and clean or replace.
					Check fan motor operation and air flow restrictions.
					Too high of external static. Check static vs. blower table.
		X	Air temperature out of range	Too much cold vent air? Bring entering air temperature within design parameters.	
	X	X	Insufficient charge	Check for refrigerant leaks.	
Low Discharge Air Temperature in Heating	X		Too high of air flow	Check fan motor speed selection and air flow chart.	
	X		Poor performance	See 'Insufficient Capacity'	
High humidity		X	Too high of air flow	Check fan motor speed selection and airflow chart.	
		X	Unit oversized	Recheck loads & sizing. Check sensible clg load and heat pump capacity.	

# CLIMATEMASTER WATER-SOURCE HEAT PUMPS

## Tranquility® 30 (TT) Series

Rev.: October 7, 2016

### Start-Up Log Sheet

**Installer:** Complete unit and system checkout and follow unit start-up procedures in the IOM. Use this form to record unit information, temperatures and pressures during start-up. Keep this form for future reference.

**Job Name:** \_\_\_\_\_ **Street Address:** \_\_\_\_\_

**Model Number:** \_\_\_\_\_ **Serial Number:** \_\_\_\_\_

**Unit Location in Building:** \_\_\_\_\_

**Date:** \_\_\_\_\_ **Sales Order No:** \_\_\_\_\_

In order to minimize troubleshooting and costly system failures, complete the following checks and data entries before the system is put into full operation.

**Fan Motor: CFM Settings (ECM)** \_\_\_\_\_

**Temperatures: F or C**

**Antifreeze:** \_\_\_\_\_ %

**Pressures: PSIG or kPa**

**Type** \_\_\_\_\_


	Cooling Mode		Heating Mode
Entering Fluid Temperature			
Leaving Fluid Temperature			
Temperature Differential			
Return-Air Temperature	DB	WB	DB
Supply-Air Temperature	DB	WB	DB
Temperature Differential			
Water Coil Heat Exchanger (Water Pressure IN)			
Water Coil Heat Exchanger (Water Pressure OUT)			
Pressure Differential			
Water Flow GPM			
<b>Compressor</b>			
Amps			
Volts			
Discharge Line Temperature			
<b>Motor</b>			
Amps			
Volts			

Allow unit to run 15 minutes in each mode before taking data.

**Note: Never connect refrigerant gauges during startup procedures. Conduct water-side analysis using P/T ports to determine water flow and temperature difference. If water-side analysis shows poor performance, refrigerant troubleshooting may be required. Connect refrigerant gauges as a last resort.**

Functional Troubleshooting

HEATING CYCLE ANALYSIS -



COOLING CYCLE ANALYSIS -


Refrigerant Type:

HFC-410A

Voltage: \_\_\_\_\_

Comp Amps: \_\_\_\_\_

Total Amps: \_\_\_\_\_



Heat of Extraction (Absorption) or Heat of Rejection =

\_\_\_\_\_ flow rate (gpm) x \_\_\_\_\_ temp.diff. (deg. F) x \_\_\_\_\_ fluid factor<sup>†</sup> = \_\_\_\_\_ (Btu/hr)

Superheat = Suction temperature - suction saturation temp. = \_\_\_\_\_ (deg F)

Subcooling = Discharge saturation temp. - liquid line temp. = \_\_\_\_\_ (deg F)

<sup>†</sup> Use 500 for water, 485 for antifreeze.

**Note: Never connect refrigerant gauges during startup procedures. Conduct water-side analysis using P/T ports to determine water flow and temperature difference. If water-side analysis shows poor performance, refrigerant troubleshooting may be required. Connect refrigerant gauges as a last resort.**