
IMPORTANT: As of 07-24-12, manufacturer's installation instructions have changed. Please read entire instruction sheet throughly before installing this product.

Shower WallNut[™]

Shower Arm Adapter



24110 South Peculiar Drive Peculiar, Missouri 64078 1.800.821.3944

1.800.758.5950





Shower WallNut™ System Installation Instructions

REQUIRED COMPONENTS FOR A WARRANTED INSTALLATION

Sioux Chief's Shower WallNut System carries a 25-Year Warranty only when all of the following Sioux Chief components are used and installed per manufacturer's instructions:

1. Sioux Chief copper stub out ell or preformed copper shower riser

3. Shower WallNut

Shower Arm Adapter



2. Strong Arm Bracket with WallNut Lock Block



Accessories

Shower Arm Tool 307-625 Patent # 6,460,432

Removal Tool 307-616



Brace copper stub out Use Strong Arm Bracket & Shower WallNut Lock Block at rough in as shown Strong Arm Sioux bracket with Chief WallNut stub Lock Block out ell

2 Sand the stub out surface After installing finish wall, sand



3 Cut off the stub out

Cut off stub out leaving exactly 11/2" to finished wall



4 **Install Shower WallNut**

> Push Shower WallNut over stub out and against wall



Cinch-back (using shower arm tool)

Insert nose Swing shower & hold tube arm tool, levering off pliers

or Cinch-back (using pliers) Swing second Insert nose pair, levering & hold tube off first pair

Install shower arm




Use brass

only.

shower arms

Hold hex then thread shower arm completely and tightly into FIP threads.

Straighten shower arm To prevent any rotation



8 Install escutcheon



Firmly push deep escutcheon onto Shower WallNut until it snaps and locks into place