

Large

Diameter


Tapcon

Anchor

R

Installation

Instructions



Installation Steps for Concrete, Lightweight Concrete and Metal Deck

1. Using a 5/16" carbide drill bit (for 3/8" LDT), drill a hole at least 1" deeper than anchor embedment.

1. Using a 5/16" carbide drill bit (for 3/8" LDT), drill a hole at least 1"

anchor until fully seated. Do not use an impact wrench for installations

MAX IMPACT

WRENCH

TOROUE

RATING

150 FT I BS

150 FT LBS

(B)

MINIMUM

EMBEDMENT

1-1/2"

1-1/2"

MINIMUM

HOLE

DEPTH

2-1/2"

2-1/2"

2. Using a manual socket wrench, insert anchor into hole and tighten


 Using an impact wrench or manual socket wrench, insert anchor into hole and tighten anchor until fully seated. If installation torque exceeds 50 ft lbs using an impact wrench, remove anchor from hole¹. Reinstall new 3/8" LDT anchor using a manual socket wrench.

Installation Steps for Hollow or Grout-Filled CMU

deeper than anchor embedment.

in hollow or arout-filled CMU.





* See catalog for effective lengths and length indication codes. LDT(X) available with corrosion resistant Envirex[™] coating.

WARNING! Always wear safety glasses and other necessary protective devices or apparel when installing or working with anchors.

CAUTION:

¹Observe torque values particularly when installing anchor in higher compressive strength concrete with an impact wrench. Over-torquing may result in lower tension and/or shear performance of the anchor.

Use of core drills is not recommended to drill holes for use with this anchor.

Not recommended for use in new concrete which has not had sufficient time to cure.

The use of carbide drill bits manufactured within ANSI B212.15 drill bit diameter requirements is recommended for installation of this anchor.

Anchor spacing and edge distance requirements (anchor installation locations) are the responsibility of the engineer of record. Call tech service for values.



© 1-800-899-7890 www.itwredhead.com 2171 Executive Drive, Suite 100 Addison, IL 60101 RH020 - REV 04/09 MADE IN USA