

Occasional cleaning and disinfection is recommended. To clean the inside of the unit, add 1/2 cup (4 fluid

oz.) of Clorox (liquid bleach) to a full tank of potable

water. Allow the mixture to penetrate for 15 minutes.

potable water. Take care to not overtighten drain cap as damage may occur. For further information about Clorox, call toll-free at 1-800-292-2200. Follow

refilling instructions in this manual and place the tank back in service. Should any repair part be required, use only genuine SPEAKMAN parts for repair or


replacement. See available replacement parts in this document, to order parts call 1-800-537-2107.


Additional warranty information can be found at:

WARRANTY

3 Year Limited Warranty

Drain tank, and rinse thoroughly several times with







Select a suitable location for the SE-4300. The location should protect the unit from freezing and potential scalding conditions. After


Mount the Wall Bracket using appropriate hardware, making sure to torque to manufacturer's specifications, if applicable.


Note: Mounting hardware not included. Ensure the mounting surface (wall, etc.) and mounting hardware can safely hold a minimum vertical load of 300 lbs.








Retrieve the Pull Strap from the accessory bag. Slide the cups over the Spray Heads individually, pressing firmly until they are fully seated. Make sure handle portion of the Pull Strap is oriented so the word "PULL" is easily seen in an upright position.























Self-contained eyewash equipment shall be visually checked frequently to determine if flushing fluid needs to be changed or supplemented. Frequency of these inspections is dependent on environment conditions, but at a minimum weekly. Failure to conduct visual checks could lead to further injury. Customer shall take precautions to help prevent the growth of potentially harmful bacteria in eyewash tanks. Either of the following procedures is recommended.


Procedure 1: Use suitable Bacteriostatic preservative to help prevent growth of bacteria in eyewash tank. Eyewash tank should be drained, flushed and refilled with clean potable water and Bacteriostatic preservative added as directed by the preservative's manufacturer.

Procedure 2: Drain, flush and refill units with clean potable water at least once every week unless site conditions require more frequent changing. Thoroughly cleanse tank at least once every month. See "Maintenance" Section for further information of cleaning unit.



SE-4300 ROUGH-IN DIAGRAM / REPAIR PARTS

SPEAKMAN®



REPAIR PARTS

FLOW DATA:							
	run time (full tank)	15 MINUTES (minimum)					
	FLOW RATE IN gpm (L/min)	.4 (1.5) MINIMUM					

DIMENSIONS	SUBJECT	TO	CHANGE	WITHOUT	NOTICE

ITEM	PART NUMBER	DESCRIPTION			
1	RPG07-0021	FILL CAP			
2	RPG38-0433	(2) SPRAY HEAD ASSEMBLIES			
3	RPG07-0022	SIDE OUTLET CAP			
4	SE-4920	DRENCH HOSE			
N/S	RPG56-0039	PULL STRAP ACTIVATOR			
N/S	RPG05-0935	(3) 12" TAMPER EVIDENT SEAL TIES			
N/S	RPG05-0901	PULL STRAP ACTIVATOR & DRAIN BULKHEAD FITTING			