9200SUR CABINET INSTALLATION

- 1 SUGGESTED ORIENTATION: CABINET PANEL OPENINGS AND VALVE PORTS ALIGNED VERTICALLY WITH DOOR LOCK POSITIONED ON RIGHT SIDE.
- 2 9202E VALVE SHOWN AS EXAMPLE ONLY. VALVE USED DETERMINES PANEL KIT SELECTION. SEE PANEL KIT / VALVE TABLE TO MATCH PANELS TO VALVE.
- 3 "A" DIMENSION = SUGGESTED CLEARANCE TO ALLOW ACCESS TO TEMPERATURE ADJUSTMENT SCREW. SEE PANEL KIT / VALVE TABLE FOR DIMENSIONING.
- TOP & BOTTOM PANELS SHOWN AS EXAMPLE ONLY. MATCH PANELS TO PORTS ON VALVES. FOR ORIENTATION OF VALVES AND ALIGNMENT OF PANELS. GO TO WWW.HAWSCO.COM AND SEE THE INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS FOR EACH VALVE. FOR TECHNICAL SUPPORT, CALL 1-800-766-5612.
- MOUNT CABINET TO WALL FROM INSIDE OF CABINET. (MOUNTING HARDWARE NOT SUPPLIED)
- 6 "B" AND "C" DIMENSIONS = DISTANCE FROM WALL SURFACE TO CENTER OF CLOSEST VALVE PORT AND PANEL CLEARANCE HOLE.

PANEL KIT / VALVE TABLE				
VALVE USED	PANEL KIT USED	"A" DIM. ±1/2"	"B" DIM. ±1/8"	"C" DIM. ±1/8"
TWBS.HF	PKHF	3 1/2"	2 3/8"	NA
TWBS.SHE	PKSHE	4"	3 1/8"	NA
TWBS.EWE	PKEWE	4"	3 1/8"	NA
9201E	PK01E	4"	3 1/8"	3 1/8"
9201EFE	PK01EFE	4"	3 1/8"	NA
9201H	PK01H	4"	2 1/16"	NA
9202E	PK02E	4"	3 1/8"	3 1/8"
2	2	3	6	6

() Haws

1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (755) 359-7424 E-MAIL: HAWS@HAWSCO.COM

WEBSITE: WWW.HAWSCO.COM
PART NUMBER

FOR STATE OF THE PROPERTY OF THE PROPERTY

9200SUR 0002076111
CABINET, SURFACE-MOUNT 16161A 1

