# **Brantford Technical Specification**

### **Grab Bar**

## YG2212/YG2218/YG2224

#### **Stock Numbers:**

- YG2212CH 12" Grab Bar Chrome Finish
- YG2218CH 18" Grab Bar Chrome Finish
- YG2224CH 24" Grab Bar Chrome Finish
- YG2212BN 12" Grab Bar Brushed Nickel Finish
- YG2218BN 18" Grab Bar Brushed Nickel Finish
- YG2224BN 24" Grab Bar Brushed Nickel Finish
- YG2212ORB 12" Grab Bar Oil Rubbed Bronze Finish
- YG2218ORB 18" Grab Bar Oil Rubbed Bronze Finish
- YG2224ORB 24" Grab Bar Oil Rubbed Bronze Finish

### Materials:

Grab Bar posts and bars are constructed of stainless steel.

#### **Compliance:**

- ADA, ANSI, ASTM, CSA
- Tested to 500lbs. pull



### **Dimensions:**



#### **Installation Instructions:**

- 1. Please note that screws MUST be mounted into a wood stud for secure installation.
- Decide whether you would like to position your grab bar horizontally, vertically or at an angle, remembering that BOTH ends of the grab bar MUST be positioned over a wood stud (unless using secure mount anchors).
- For easier installation and mounting remove 3 set screws from each flange and remove bar from SecureMount<sup>™</sup> Flange.
- 4. Remove cover and re-assemble flange to bar by tightening 3 set screws.
- Place grab bar and mark three mounting locations on each of the two grab bar flanges with a pencil.
- 6. Drill 1/8" diameter pilot holes at each screw location. Make sure to drill into the stud.
- Install 3 screws and washers each SecureMount<sup>™</sup> flange and tighten until secure. If desired, apply silicone caulk to the back of the SecureMount<sup>™</sup> plate to guard against water penetration.
- 8. After screws are installed each side, dis-assemble bar from SecureMount<sup>™</sup> flange by removing set screws.
- 9. Re-install covers.
- 10. Place bar over SecureMount<sup>™</sup> flanges and tighten all set screws.
- 11. Snap on covers.

#### **Cleaning Instructions:**

To preserve the fine finish of this product, clean only with a soft damp cloth. Dry well. Do not use commercial or abrasive cleaners.

Stock Number:\_\_\_\_

By Moen Incorporated

Grab Bar

25300 AL MOEN DRIVE • NORTH OLMSTED, OH 44070 CORPORATE HEADQUARTERS: (800) 321-8809 • FAX: (800) 848-6636 INTERNATIONAL: (440) 962-2000 • FAX: (440) 962-2726 CUSTOMER SERVICE (USA): 800-882-0116 • FAX: (888) 379-2720 WWW.MOEN.COM

© 2015 Moen Incorporated. Moen is a registered trademark and Brantford is a trademark of Moen Incorporated. All rights reserved.