



Command Center™/MC

Dispensing System

The push-button dispensing system that dilutes market-proven products.

Features & Benefits

- Dispenses up to four different products that are numbered and color coded for easy identification and training
- Patented dispensing technology ensures that products are dispensed accurately, eliminating the need for manual mixing
- Uses super concentrated products which results in less inventory/packaging waste
- Available in 4 button and 1 button units with bottle or bucket fill options. Single buttons can be joined together or added to a four button system for a multitude of dispensing options

Applications

- Designed for Lodging, Healthcare, Education, Government, Retail and BSC
- Dispenses ready-to-use product into both buckets and bottles





Command Center™/MC

Dispensing System

Use Overview

Command Center™/MC Dispensing System four-product and one-product units provide ultimate versatility. One-product satellite units can be joined together or to a four-button unit in any combination of bottle or bucket fill. Easy-to-mount wall bracket holds system securely in place. Adjustable dilutions provide maximum economy and performance.

Technical data	Command Center™/MC 4 button	Command Center™/MC 1 button
Depth	14 in.	14 in.
Height	23.5 in.	23.5 in.
Width	23.5 in.	6 in.
Weight (with product)	80 lbs (36 kg)	
Water In-Let Hose	4 ft. (1.22 m)	4 ft. (1.22 m)
High Flow Rate	4 gpm	4 gpm
Low Flow Rate	1 gpm	1 gpm
Operating Range Requirements	Water Pressure: 30–85 psi (170–580 KPA) Water Flow: > 2.0 gal./min. (7.6 L /min.) Water Temperature: 50–100° F (10–40° C)	Water Pressure: 30–85 psi (170–580 KPA) Water Flow: > 2.0 gal./min. (7.6 L /min.) Water Temperature: 50–100° F (10–40° C)

ASSE 1055-B backflow prevention requirements.

Product	Description	Product code	
Command Center™/MC	4 Button Unit with E-Gap Eductors	D5055764	
Command Center™/MC	4 Button Unit with Air Eductors	D5055748	
Command Center™/MC	1 Button Unit Bottle Fill E-Gap Eductors	D4375900	
Command Center™/MC	1 Button Unit Bucket Fill E-Gap Eductors	D4376900	

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.