

Diversey

Snapback™ UHS Restorer



Specially-formulated to restore and maintain a continuous “wet look” with UHS burnishing.

Effective

- Fills in scratches and scuffs to maintain a smoother, deeper gloss when burnished
- Prevents finish build-up

Enhances Floor Appearance

- Helps maintain a continuous “wet look”
- “Pops” the gloss when burnished with any UHS equipment
- Saves times and labor

Cost-Effective

- Dilutes 1:4 with water
-



Use Directions

- Blockade areas to be stripped or finished. Floors will be very slippery until dry.
- Dust mop or sweep floor.
- Scrub floor using Diversey UHS Cleaner. Use blue or purple scrubbing pad and dilute product as follow 1:512.

Note: UHS Cleaner dispenses in a dispensing system of a dilution of 1:512 (2 mL/1 L)

- Dilute one part Snapback™ UHS Restorer with four parts cool water (1:4) and mop a light even coat of diluted product onto floor.
- Allow Snapback™ UHS Restorer to dry thoroughly. Burnish floor after drying to maximize appearance. Use a light UHS burnishing pad with 1000–2500 rpm burnisher.
- Dust mop floor after burnishing. Do not use on Carefree® Matte. For use only with rotary buffing machines on commercial floor finishes.

Product Specifications

Description	
Color/Form	Cloudy, blue liquid
Flash Point	>200° F (> 93.4° C)
pH	8.4 (Concentrate) 8.5 (Use Dilution 1:4)
Scent	Slight ammonia lemon
Shelf Life	2 years
Solubility	Complete
Specific Gravity	1.02

Available Items

Product Code	Description/Package Size	Dilution
04134	4 x 1 gallon / 1.89 L Containers	1:4

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up to date shipping information.