



Regular and thorough cleaning of your interceptor assures maximum operating efficiency. Here's what you need to know:

When to Clean Your Interceptor

It is time to clean your Rockford interceptor when you notice a gradual slowdown of the drainage at the fixtures that are draining into the unit. With normal use, you should be able to establish a cleaning cycle. Whether once a week, or once a month. A thorough and regular cleaning each time will assure maximum operating efficiency, and will extend the life of your interceptor.

Rockford does not recommend adding enzymes or other short-circuiting products to a grease interceptor.

How to Clean Your Interceptor

1. Remove the cover attachment bolts, and remove the covers.
2. Remove any floating waste materials.
3. Remove all filter screens, and clean. **DO NOT DISPOSE OF ANY WASTE INTO THE SEWER.**
4. With the parts removed, scoop or pump out all remaining solids that have accumulated on the bottom of the unit.
5. Replace all parts. Call Rockford if your separator parts are in need of replacement. All parts are usually in stock and can be shipped UPS.
6. Run enough water to the separator, to restore the trap seal.
7. Before replacing the cover, inspect the gasket. Rockford always has replacement gasket in stock.
8. Install cover, making sure all bolts are tightened evenly.

How to Replace a Gasket

1. Remove all gasket, from the underside of the cover and or from the top lip of the separator. Once removed and surface is clean, cut the new gasket to approx. a .50" longer than needed.
2. Rockford RLSW units. The gasket has a self-adhesive on one side. The adhesive side goes on the separators top lip. Making sure to fill in corners tightly. Where the bolts come through the cover, you may pierce a hole in the gasket, using a .50 hole punch, or similar type tool.