

## QUICK SHAKE PUMP

Installation Instructions:

1. The end of the drain tube must be lower than copper shaker end before siphoning will start.
2. Submerge copper shaker end into liquid that is to be siphoned.
3. Grab hose in a comfortable location above copper shake and move quickly in an up and down motion.

**IMPORTANT:** The copper shaker must remain in liquid at all times.

4. Once the flow starts, stop shaking and allow liquid to flow on its own.
5. To stop the flow at any time, remove copper shaker from liquid.
6. Drain all liquid and clean thoroughly for safe storage.

## BOMBA DE AGITADOR

Instrucciones de Instalación:

1. El extremo del tubo de drenar debe estar más abajo del agitador antes de empezar el trasvase de sifón.
2. Sumergir el agitador de cobre en el líquido que ha de ser transferido.
3. Agarre la manguera por encima del agitador de cobre, y con movimientos rápidos mueva hacia arriba y hacia abajo.

**IMPORTANTE:** . El agitador debe permanecer dentro del líquido en todo momento.

5. Una vez que se inicia el flujo, deje de agitar y permita que el líquido fluya por sí solo.
6. Para detener el flujo, retire el extremo del agitador del líquido.
7. Drenar todo el líquido de la manguera y limpie a fondo para un almacenamiento seguro.

