


FIG.	PART NO.	DESCRIPTION OF PART N	O. REQ.
1	34-60-0725	Retaining Ring	(1)
2	45-88-2026	Washer	(1)
3	40-50-1470	Spring	(1)
4	45-22-2657	Sleeve	(1)
8	45-88-2653	Plastic Washer	(1)
9	02-02-1100	4.0mm Steel Ball	(2)
10	42-06-2750	1/4" Hex Anvil	(1)
11	02-02-1300	5mm Steel Ball	(1)
24	44-66-0425	Gearcase End Cap with Ball Bearing	(1)
25	06-82-7236	4-20 x .625 Pan Hd. Plast. T-10 Screw	(8)
26	43-72-0550	Bit Holder (Optional)	(1)
27	06-82-0130	6-32 x 5/16" Pan Hd. T-15 Screw	(2)
28		Housing Cover - Right Housing Halve	(1)
29	05-86-0300	M3.0 x 22.5mm Pan Hd. ST T-10 Scre	w(1)
31	45-30-1000	Rubber Slug (Battery area of housings	s) (4)
32		PCBA	(1)
34		Stator Assembly	(1)
35	42-42-0235	Forward/Reverse Shuttle	(1)
36	45-30-2653	Rubber Slug (Stator area of housings)	(4)
42		Belt Clip	(1)
43		Housing Support - Left Housing Halve	(1)
44	40-50-1090	Compression Spring	(1)
46		Terminal Connector Block	(1)
47		On-Off Switch	(1)
48	28-50-0017	Gearcase Assembly with Bushing	(1)
50	14-46-0132	Impacting Assembly	(1)
52	14-20-2750	Electronics Assembly	(1)
53	16-07-0054	Rotor Assembly	(1)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
60	31-44-0057	Housing Assembly	(1)
61	42-70-2653	Belt Clip Kit	(1)
62	23-94-0027	High Voltage Wire with Contact Plate	e (1)
63	12-20-2651	Service Nameplate	(1)
64	42-55-2750	Blow Molded Carrying Case	(1)

FIG. LUBRICATION (Type 'J' Grease, No. 49-08-4220):

- 10 Lightly coat front washer surface of anvil with grease, place a dab in the ball cavities of anvil.
- 35,47 Be sure that oval slot in shuttle is over round pin on switch.
- 48 Coat inside of bushing inside front gearcase with grease.
- 50 **NOTE:** Do not wash impact assembly. Use a clean, dry cloth to wipe away any excess grease or contamination.
- 50 Lightly coat the I.D. of the ring gear and the center of the planet gears of impacting assembly with grease.
- 53 Coat pinion of rotor assembly with grease.
- 62 High voltage wire assembly is a component of the electronics assembly as well as an individual service part.



PRIOR TO INSTALLING THE HANDLE COVER ONTO THE HANDLE SUPPORT, BE SURE THAT THERE ARE NO INTERFERENCES.