

C100+



CLEANING GUIDE



PLEASE CLEAN THE FOGGER AFTER EACH USE!



When using water based liquids

STEP A: When fogging is completed, pour any liquid left in the tank to a suitable container, using a funnel.

STEP B: Operate the fogger for 1 minute with the nozzle opened to the largest droplet size setting. This will get rid of any existing liquid remaining in the fogger's internal tubes.

STEP C: Fill the fogger with some clean water and operate again for one minute. Remove any excess water from the tank.

When using emulsions

After fogging, begin with **STEP A** as listed above. Once done, fill the tank with appropriate solvent for the chemical that was used.

Repeat **STEP B**, flushing any chemical residuals left inside. Then repeat **STEP C**. Before storing, allow the tank to dry.

VECTOR FOG™