



## INSTALLATION INSTRUCTIONS

1. Rockford interceptors should be installed as close as possible to the fixture being serviced, and where it can easily be accessed for cleaning.
  - a. When installing the interceptor flush with grade, the cover must be installed and the unit filled with water before the backfilling process.
  - b. When suspending the interceptor from a floor above, the bottom of the unit must be fully supported and be able to withstand the weight of the unit and its contents.
2. A provided flow control device must be installed as close as possible to the fixture (NOT the interceptor). Install so that the orifice plate is upstream of the vent/air intake. The air intake must extend upward to at least the top of the fixture.
3. Rockford recommends installing a clean-out tee up stream of the flow control to aid in clearing any blockages.
4. Install the P-Trap up stream of the interceptor.
5. The outlet piping should match that of the interceptor. Vent the outlet pipe, so the interceptor is not siphoned.
6. The static water level in the unit is a line between the bottom of the inlet to the bottom of the outlet.
7. Solid wastes should not go to the interceptor. Solids should be caught in the sink strainer, or by a separate solids interceptor prior to the grease interceptor. If there is a problem with blockages due to solids, either at the flow control, and or the interceptor, a solids interceptor must be installed. Call Rockford for your solids interceptor needs. Most sizes are in stock.

**NOTE:** All interceptors must be installed per local codes.

