

Schedule 40 Flexible Bath Waste Kit with Quick Test

Parts List

| | |
|-------------------------------------|-----------------------|
| A. Stopper Assembly | I. Overflow Gasket |
| B. Spud | J. Retainer Nut |
| C. Drain Gasket | K. Overflow Faceplate |
| D. Drain Elbow | L. O-Ring |
| E. Schedule 40 Pipe (Drain Tube) | M. Test Nut |
| F. 1.5" Tee | N. Test Cap |
| G. Schedule 40 Pipe (Overflow Tube) | O. Test Cap Gasket |
| H. Overflow Elbow | |

Additional Parts Needed

- Pliers
- PVC Cement

NOTE: These instructions are general recommendations for installation. Local code requirements supersede these instructions.

Installation Instructions

1. Cut the 1-1/2" Schedule 40 pipes (E and G) to the desired lengths to fit the tub.
2. Use a primer, then Type-N Medium solvent cement to assemble the bath drain pipes and fittings (D - H).
3. Place the overflow gasket (I) onto the overflow elbow (H) and insert into the tub overflow hole from the back of the tub.
4. Screw the retainer nut (J) onto the overflow assembly from the inside of the tub. Hand-tighten only.
5. Secure the drain elbow (D) and drain gasket (C) under the tub, by screwing in the spud (B) through the tub drain hole from inside the tub.
- If not testing, skip to Step 9.
6. Screw the test cap and gasket (N and O) into the spud (B).
7. If the test membrane has been removed, screw the test nut and o-ring (M and L) over the opening.
8. Test the system. Once testing is complete, remove the test cap and gasket (N and O) and the test nut and o-ring (M and L), if installed.
9. If still intact, cut away the test membrane from the overflow elbow (H).
10. Snap on the overflow faceplate (K) with the slot facing downward.
11. Install the stopper assembly (A) into the spud (B).

Note: Stopper assembly (A) may vary depending on the type of stopper assembly being used.

