







### **INCLUDED**

- 1x ScentNote Diffuser
- 1x ScentNote Manual
- 1x SafeLock & Key
- 1x Atomizing Head
- 1x Wall Mount Bracket
- 1x Wall Mounting Hardware (2 wall anchors + 2 screws)
- Bottle w/ScentBridge fragrance oil, USB-C Power Cord, D Battery sold separately









Hardware

Wall Mount Bracket

Atomizina



# **INSTALLING FRAGRANCE**

- 1. Insert the SafeLock key in the left side of the diffuser and twist it to the left to unlock, then remove lock
- 2. Lightly press down on the fixed button on top to open the door of the diffuser
- 3. Remove the atomizing head by pulling it toward you
- 4. Insert the straw into a bottle of ScentBridge fragrance oil and tighten atomizing head fully
- 5. Reinstall the atomizing head with attached fragrance bottle back into the diffuser
- 6. Choose Power or Battery mode by sliding the labelled switch; plug in or insert battery
- 7. Wait ~12 minutes to charge if the diffuser has not been powered on in over 7 days
- 8. Close door, reinsert SafeLock if desired (diffuser will operate normally even if lock is not inserted)
- 9. Adjust grade settings and schedule as needed in Scent Marketing App



# **CAUTION / WARNING**

- 1. Keep the machine upright. Tilting or laying flat will cause the oil to over flow
- 2. ScentBridge fragrance oil is specially formulated to work optimally with all ScentBridge diffusers. Other oils may cause damage or poor performance
- 3.Do not use quick charger to power diffuser
- 4. Do not disassemble or attempt to repair the diffuser. If any failure happens to the machine, please see the Troubleshooting section



# **SPECIFICATIONS**

100ml **Bottle Capacity:** Input Voltage: DC5V 1.5W Power:

Coverage: up to 250 sq.ft.

Material: Plastic Weight: 450g

> White / Black Color:



# **CLEANING**

The machine should be cleaned when:

- · You're are switching to a different oil
- The atomization volume becomes weak

#### Cleaning steps:

- Remove the atomizing head & bottle from the diffuser
- Separate the head from the bottle and place the bottle safely where it won't spill
- Use a larger container filled with industrial alcohol to soak the atomized head for 5-10 minutes
- Allow the atomized head to air-dry then reinstall















### **APP GUIDE**

Search the Google Play Store (Android) or the App Store (iOS) for "**Scent Marketing**"

#### TO LOG IN

- Ensure Bluetooth \$\frac{1}{3}\$ is enabled on your smart device
- Open the app and select "Bluetooth Version"
- Tap diffuser name (default is a string of letters and numbers that can be renamed later)
- Enter the default password "8888" and tap "Login"
- The system will beep when connected

Tap either Name or Label to edit, then tap 'save'



### TO ADD WORKING PERIODS (add up to 5)

Press (+) to add a new Working Period



The schedule example above will diffuse fragrance Monday through Friday from 6AM - 1PM at Grade 4, Then Saturday and Sunday 2PM - 11PM at Grade 2



### **APP GUIDE**

#### TO EDIT WORKING PERIODS

Start working time: When diffusion will begin
Stop working time: When diffusion will cease
Grade: Strength of diffusion. The larger the grade, the

stronger the fragrance. Details on last page



#### TO CHANGE PASSWORD

Tap "About"

Tap "Change Password"

Enter new password and tap "Confirm"



### OPTIONAL WALL MOUNTING

- Line up the mounting bracket where you would like to install the diffuser on the wall
- 2. Drill holes in the wall. Insert the wall anchors, then the screws, then tighten the bracket to the wall
- 3. Hang the diffuser on the bracket























# **TROUBLESHOOTING**

Before reaching out to our technical personnel, please take a look at the following possible solutions. If you need further assistance, please email us at service@scentbridge.com

#### **Diffuser Not Connecting to Smart Device:**

- Quit the Scent Marketing app
- Turn off Bluetooth on your smart device, then unplug or remove battery from ScentNote diffuser
- Turn the smart device's Bluetooth back on, then plug ScentNote diffuser back in or reinsert battery
- Listen for the diffuser to beep, then open the Scent Marketing app and select the diffuser

#### Weak or No Diffusion:

- Check to ensure the machine is not in a "nonworking period"
- The air pump may be damaged, replace if still under warranty
- Check to ensure the tube is not loose

#### Oil Leaking or Spraying:

- Check to ensure the bolt is not loose
- The gasket in the atomizing head may be damaged or loose
- The atomizing head is damaged, contact support if still under warranty



# **GRADES & CONSUMPTION**

All Grades repeat a diffusion period of 3 seconds followed by a pause interval

Grade	Pause Interval (minutes)	Approximate Consumption (mL/hour)
1	15	0.04
2	13.5	0.05
3	12	0.06
4	10.5	0.07
5	9	0.08
6	7.5	0.13
7	6	0.19
8	4.5	0.24
9	3	0.3
10	1.5	0.35





