

Installation Instructions

Butyl Sealing Tapes



Sealant Placement Procedures

The following procedures should be followed for optimum sealant performance.

- Clean the upper and lower joint surface with a stiff bristle brush.
- Remove any dirt, debris, flashing, or concrete high points, which could keep the joint from coming together.
 - If necessary, a joint primer (i.e. CS-50) can be applied to improve sealant adhesion.
 - When using a primer, allow the primer to dry before placing sealant. The primer will normally be dry to the touch within 15-20 minutes.
(Note: Primer can be applied at the job site or at the plant several days in advance of the set.)
- Place sealant on the lower joint in the correct location.
DO NOT PLACE ANY JOINTS WITHIN 12" OF A CORNER.
- Join the sealant into one continuous strand by kneading the ends together where they meet.

DO NOT STRETCH THE SEALANT. DO NOT OVERLAP THE SEALANT.

- Once the sealant is installed, do not:
 - Step on the sealant
 - Allow dirt or debris to fall on the sealant

Note: Plastic sheeting may be installed over the sealant if necessary.
- A **minimum** compression of 50% is required. Greater than 50% compression is optimal. It may take 15-20 minutes for the sealant to fully compress. This will vary according to the ambient temperature and the weight being applied.

Disclaimer: This publication is to assist users to understand the proper use of ConSeal's products. *Contact ConSeal's technical staff for installation instructions that meet your specific requirement.* Concrete Sealants, Inc. does not warranty any improper use of its products.

Don't Just Seal It, ConSeal It!

© 2018 Concrete Sealants, Inc.

Concrete Sealants, Inc. 9325 State Route 201 ■ Tipp City, OH 45371 ■ **Toll Free** 800.332.7325

P. 937.845.8776 **F.** 937.845.3587 ■ **www.conseal.com**



Concrete Sealants, Inc.
ISO 9001:2015 Registered