



INSTALLATION STEPS

Installation Steps in Concrete




1. Using the proper size carbide bit (see chart) drill a pilot hole at least 1" deeper than anchor embedment.




2. Using an electric impact wrench, or socket wrench (hand install) insert anchor into hole and tighten anchor until fully seated. (see chart for socket size)

Installation Steps in Concrete Block (CMU) (3/8" and 1/2" diameter)



1. Using a 5/16" (for 3/8" LDT) or 7/16" (for 1/2" LDT) carbide tipped bit, drill a pilot hole at least 1" deeper than anchor embedment.



2. Using a socket wrench insert anchor into hole and hand tighten anchor until fully seated. (9/16" socket for 3/8" and 3/4" socket for 1/2")

LDT	Bit Size	Socket Size
LDT 3/8"	5/16"	9/16"
LDT 1/2"	7/16"	3/4"
LDT 5/8"	1/2"	13/16"
LDT 3/4"	5/8"	15/16"