

**STEP 1:**

Using an SDS 250 carbide tip bit or a HEX RECEIVER with a #250 carbide tip bit, pre-drill the concrete member to a depth of 2" with an impact/drill set on impact mode.




**STEP 2:**

After pre-drilling has been completed, install the SLEEVE TOOL over the bit (the bit should remain in the drill), and insert the #14SW (red) nut driver into the opposite end.




**STEP 3:**

Install the **SAMMYS** SWC screw into the nut driver.



**STEP 4:**

Place tip of screw into the pre-drilled hole, set to drill mode and begin insertion. When the nut driver spins free on the SWC screw, installation is complete. Stop and remove drill.



**STEP 5:**

The SWC screw is ready to receive 1/4", 3/8" or metric all thread rod or bolt stock.

**Note:** Use a 1200 maximum RPM drill for installation.

**Note:** Do not install concrete screws while the drill unit is in impact mode — doing so will destroy the pullout factor of the fastener.

**Important Note:** Warranty requires the use of the appropriate Sammy Nut Driver for installations.