

# ADJUSTABLE FLOOR DRAIN



Approval  
Date

Customer  
Approval


Job  
Location

Job  
Name

Wade Division / Tyler Pipe Assumes No Responsibility For Superseded or Voided Data

## 1100-STD

CAST IRON ADJUSTABLE FLOOR DRAIN WITH SATIN FINISH NICKEL BRONZE STRAINER ASSEMBLY, VANDAL PROOF SECURED GRATE AND BOTTOM OUTLET. INSTALLATION INSTRUCTIONS



The Wade 1100-STD adjustable floor drain is for most floor constructions. The drain piping is first run to an elevation below the expected finish floor level. The piping must include a p-trap and the drain body is secured to the pipe with any of four connections; Threaded, No-Hub, Inside Caulk, or Push-On Ty-Seal. The type of connection must be specified upon ordering any Wade Drain. If the Ty-Seal connection is specified, apply Tyler Ty-Seal lubricant to the inside surfaces of the gasket and then firmly push the drain body onto the pipe until it contacts the pipe stop in the body. No-Hub outlets should be installed with Tyler or Anaco/Husky couplings and secured with a torque wrench to the manufacturers recommendations. Threaded or Inside Caulk connections should follow standard industry practices. Once the body is connected to the pipe, the initial concrete sub-floor is poured to an elevation level with the top flange of the drain body. The waterproofing membrane is applied to the the sub-floor surface and over the drain body. The clamping collar is then placed onto the drain and secured - the membrane must be clamped between the body and the clamping collar. The adjustable strainer assembly threads into the clamping collar and is adjusted to the desired dimension. The top of the strainer should be at the finish floor level or slightly below. Note that the top of the strainer assembly should be above the structural slab to accomodate the finish floor material. Care must be taken to protect the top during installation. A plastic cover is provided and should remain in place until after the installation of the finish floor is complete. If the plastic protector is lost, use either cardboard, tape or other protective materials.

AutoCad.dwg