



PEX Supply Tubes

Installation

- The plain end of the riser should be cut clean and square. Make sure the tubing bottoms out in supply stop body to ensure a good seal. Use supplied plastic compression sleeve only.
- 3/8" OD plastic tubing and smaller the use of a plastic sleeve is required.
- Pipe dope, compounds and sealants should not be used for installation because they have been known to cause leakage.
- Hand tighten ballcock nut - DO NOT OVERTIGHTEN
- 3/8" metal nuts - hand tighten plus 1-1/2" to 2-1/2" additional turns.
- When properly tightening the compression sleeve should not allow the tubing to be removed by hand.

Wolseley's North American operating companies assume no responsibility for failure due to improper installation.

Model Numbers

| | | |
|-----------|------------|----------------|
| PF3812LR | 3/8" x 12" | Lavatory Riser |
| PF3820LR | 3/8" x 20" | Lavatory Riser |
| PF3830LR | 3/8" x 30" | Lavatory Riser |
| PF3836LR | 3/8" x 36" | Lavatory Riser |
| PF3812CRX | 3/8" x 12" | Closet Riser |
| PF3820CRX | 3/8" x 20" | Closet Riser |