

# In-Wall Lavatory Kit

## Installation Instructions

Model No. 1-560

We recommend Installation of this product by a Professional Plumbing Contractor

**Note:** Use Teflon tape or equivalent to seal all threaded port joints.

**Warning:** To prevent severe damage to valve body, any solder/braze process must be performed a min. of 4" from ports.


**Important:** REMOVE CARTRIDGE FROM VALVE BODY (1) PRIOR TO APPLYING ANY HEAT/FLAME.

- Utilizing a 1/2" copper supply piping, thread or sweat pipe fittings into inlets of valve BODY (1), (blue STEM (4) is cold, red STEM (5) is hot). If sweating supplies directly to valve inlets, remove cartridges during this process.

**Note:** If cartridges are removed during installation, re-torque to factory specification of 14-16 ft-lbs.

- Secure valve BODY (1) to cross BRACE (2) using plumbing STRAPS (3), not included.
- Check the horizontal and vertical level of valve BODY (1) by placing bubble level on STEMS (4, 5). Make any necessary adjustments.
- Turn on water supply, pressurize system and check for leaks.
- Finished wall dimensions are shown in Figure 1A
- For handle trim attachment, the following table shows required stem length from finished wall:

Stem Length	Trim Model #
1-5/16"	G27-011 G27-111
1-3/16"	G28-121



# GINGER®