

ABK-20

ANCHOR BRACKET KIT INSTRUCTIONS

Attention Installing Personnel

As a professional installer you have an obligation to know the product better than the customer. This includes all safety precautions and related items.

Prior to actual installation, thoroughly familiarize yourself with this Instruction Manual. Pay special attention to all safety warnings. Often during installation or repair it is possible to place yourself in a position which is more hazardous than when the unit is in operation.

Remember, it is **your** responsibility to install the product safely and to know it well enough to be able to instruct a customer in its safe use.


Safety is a matter of common sense...a matter of thinking before acting. Most dealers have a list of specific good safety practices...follow them.

The precautions listed in this Installation Manual are intended as supplemental to existing practices. However, if there is a direct conflict between existing practices and the content of this manual, the precautions listed here take precedence.


Description

This anchor bracket is for use with condensers and heat pumps and can be installed without accessing the inside of the unit. Consult the product specifications applicable to your model.

NOTE: Please contact your distributor or our website for the applicable product specifications referred to in this manual.

 **WARNING**

HIGH VOLTAGE!
DISCONNECT ALL POWER BEFORE SERVICING OR INSTALLING THIS UNIT. MULTIPLE POWER SOURCES MAY BE PRESENT. FAILURE TO DO SO MAY CAUSE PROPERTY DAMAGE, PERSONAL INJURY OR DEATH.




Kit Contents

- Installation Instructions x 5
- Anchor Bracket x 20

Installation Instructions

1. Disconnect all electrical power.
2. Insert an anchor bracket in each of the four (4) slots on the underside of the basepan, one on each side. **NOTE:** These slots are the same slots utilized by the hold down bracket during shipment.
3. When the anchor bracket is engaged in the slots, pull the bracket outwards and swing down to lock the bracket in place.



INSTALL BRACKET THRU SLOT IN BASE, PULL OUTWARDS AND SWING DOWN TO LOCK. USE 1/4" TAPCON® TYPE CONCRETE SCREWS TO SECURE.

4. Attach the anchor brackets to the pad, using either 1/4" diameter Tapcon® concrete screws or similar self-tapping concrete screws. The minimum screw length should be 1-1/4". Two screws are required for each bracket. Follow manufacturer's instructions for installing screws.
5. Reconnect the electrical power.

NOTE: SPECIFICATIONS AND PERFORMANCE DATA LISTED HEREIN ARE SUBJECT TO CHANGE WITHOUT NOTICE

Quality Makes the Difference!

All of our systems are designed and manufactured with the same high quality standards regardless of size or efficiency. We have designed these units to significantly reduce the most frequent causes of product failure. They are simple to service and forgiving to operate. We use quality materials and components. Finally, every unit is run tested before it leaves the factory. That's why we know. . . **There's No Better Quality.**

Visit our website at www.daikincomfort.com, www.goodmanmfg.com or www.amana-hac.com for information on:

IO-329A
12/2013

- Products
- Warranties
- Customer Services
- Parts
- Contractor Programs and Training
- Financing Options

© 2007, 2013 Goodman Manufacturing Company, L.P.



is a registered trademark of Maytag Corporation or its related companies and is used under license. All rights reserved.

