

A STEP-BY-STEP GUIDE FOR INSTALLING POLYETHYLENE ENCASEMENT ON DUCTILE IRON PIPE

*Effective, Economical Protection for Ductile Iron Pipe
In Corrosive Environments*

THIS POLYETHYLENE SLEEVE (polywrap) is placed on Ductile Iron pipe to prevent corrosion. It does not have to be sealed watertight, but it should be installed so that no dirt or bedding material comes in contact with the pipe. All lumps of clay, mud, cinders, etc., on the pipe surface should be removed before the pipe is covered with polyethylene. If the polyethylene is damaged, it must be repaired before the trench is backfilled.

Small holes or tears can be repaired with a piece of tape placed over the hole. Large holes or tears should be repaired by taping another piece of polyethylene over the hole.

Overlaps, ends, and repairs can be held in place with tape or plastic tie straps until the trench is backfilled.

Other general tips for proper installation include:

- *When lifting polywrapped pipe with a backhoe, it is best to use a crescent pipe tong that fits the pipe size. The next best option is to use a fabric-type “sling” or padded cable to protect the polyethylene.*
- *When installing polywrap below the water table or in areas subject to tidal action, seal as thoroughly as possible both ends of each polyethylene tube with adhesive tape or plastic tie straps at the joint overlap. Also, place tape or plastic tie straps at two (2) foot intervals around the polyethylene wrapped pipe with the excess material folded over the top of the pipe.*
- *Quality of installation is more important than the actual sequence followed.*

***For More information, Please contact Northtown Company:
5202 Argosy Ave., Huntington Beach, CA 92649***

Phone: 714-897-0700 - Fax: 714-897-0600

TOLL FREE: (800) 972-7274

Web Site: <http://www.northtowncompany.com/polywrap.html>