The new degree of comfort.™

Uncased Coils For Gas And Oil Furnaces



RCF- Series

featuring Industry Standard R-410A Refrigerant Airflow Capacity 600-1,900 CFM [283-897 L/s]





- Rheem® Indoor Replacement Coils are designed for use with Rheem outdoor units and are available for vertical upflow or downflow, and horizontal left or horizontal right airflow. When matched with Rheem outdoor units, the coils provide a nominal capacity range from 18,000 BTU/HR [5.24 kW] to 60,000 BTU/HR [17.6 kW].
- Constructed of aluminum fins bonded to internally grooved aluminum tubing.
- Coils are tested at the factory with an extensive refrigerant leak check.
- Coils have copper sweat refrigerant connections.
- Feature two sets of 3/4" [14.1 mm] N.P.T. Condensate drain connections for ease of connection.


- Chatleff metering device connections.
- Approved for system application with variety of Rheem outdoor units.
- Condensate drain pan is constructed of high grade, heat resistant, corrosion free thermal-set material.
- Compatible with Germicidal Light System (UV resistant)
- Bi-Directional airflow eliminates the need to switch any internal components from horizontal left to right.
- Unique drain pan design maximizes application flexibility and condensate removal.
- N-Coil design maximizes performance and minimizes height required at installation.



TABLE OF CONTENTS

Model Number Identification	3
Coil Specifications	3
Coil Dimensions and Weights	4
Accessories	5-6
Limited Warranty	7

Model Number Identification



New Replacement Available Coils						
RCF2414STAVUA	RCF2417HTAVUA					
RCF2417STAVUA	RCF2421HTAVUA					
RCF2417MTAVUA	RCF3624HTAVUA					
RCF2421MTAVUA	RCF4824HTAVUA					
RCF3617STAVUA	RCF6024HTAVUA					
RCF3621STAVUA	RCF2417SPAVUA					
RCF3621MTAVUA	RCF3617SPAVUA					
RCF3624MTAVUA	RCF3621SPAVUA					
RCF4821STAVUA	RCF4821SPAVUA					
RCF4824STAVUA	RCF4824SPAVUA					
RCF6024STAVUA						

Table 1: Coil Specifications/Airflow Pressure Drop

	•							•									
Coil Design	Approx. Design Air Flam	Area F	Fins-in.			;	Static Pre	ssure Dro	p Through	Wet Coo	ling Coil [kPa] (Incl	nes W.C.)	CFM [L/s	l		
Model RCF	Air Flow CFM [L/s] Range	Sq. Ft. [m²]	Rows Deep	600 [285]	700 [330]	800 [380]	900 [425]	1000 [470]	1100 [519]	1200 [565]	1300 [614]	1400 [660]	1500 [708]	1600 [755]	1700 [802]	1800 [850]	1900 [897]
HIGH EFFI	CIENCY C	OOLING	G COILS														
2414S	600/900 [283/425]	4.56 [0.42]	16/2	.22 [.055]	.29 [.072]	.36 [.090]	.44 [.110]	_	_	_	_	_	_	_	_	_	_
2417S	600/900 [283/425]	4.56 [0.42]	16/2	.15 [.039]	.19 [.049]	.23 [.059]	.30 [.076]	_	_	_	_	_	_	_	_	_	_
2417H/2417M 3617S	600/1300 [283/614]	5.70 [0.53]	16/2	.11 [.03]	.14 [.035]	.17 [.043]	.21 [.053]	.26 [.064]	.31 [.080]	.36 [.092]	.41 [.103]	_	_	_	_	_	_
2421M/2421H 3621S	600/1300 [283/614]	5.70 [0.53]	16/2	.08 [.03]	.11 [.08]	.14 [.035]	.18 [.047]	.23 [.058]	.27 [.069]	.31 [.080]	.37 [.094]	_	_	_	_	_	_
3621M/4821S	900/1700 [425/802]	8.55 [0.79]	16/2	_	_	_	.15 [.03]	.18 [.045]	0.2 [.05]	.22 [.056]	.25 [.063]	.28 [.071]	.32 [.081]	.36 [.092]	.41 [.103]	_	_
3624M/4824S	900/1700 [425/802]	8.55 [0.79]	16/2	_	_	_	.15 [.03]	.18 [.04]	.20 [.05]	.22 [.056]	.25 [.063]	.28 [.071]	.32 [.081]	.32 [.081]	.41 [.103]	_	_
3624H/4824H 6024S/6024H	900/1900 [425/897]	9.98 [0.93]	14/3	_	_	_	.09 [.02]	0.11 [.03]	0.14 [.03]	0.16 [.04]	0.19 [.05]	0.21 [.05]	0.24 [.06]	.27 [.070]	.30 [.076]	.34 [.084]	.37 [.094]

NOTE: Represents Coil-Only Airflow Ratings

[] Designates Metric Conversions

Table 2: Coil Dimensions and Weights

	Conne	ctions	Cased Coil	Dimensions			
Coil Model	Sweat (ii	n.) [mm]		(in) [mm] Weight			
RCF	Liquid	Suction	٨	В	Coil Weight	Shipping Weight	
	I.D.	I.D.	A	U	(lbs.) [Kg.]	(İbs.) [Kg.]	
2414S *	3/8 [9.53]	3/4 [19.05]	21 [533]	14 [356]	43 [19]	47 [21]	
2417S	3/8 [9.53]	3/4 [19.05]	141/2 [368]	171/2 [445]	43 [19]	48 [22]	
2417M3/2417H/3617S	3/8 [9.53]	3/4 [19.05]	177/8 [454]	171/2 [445]	49 [22]	54 [24]	
2421M/2421H/3621S	3/8 [9.53]	3/4 [19.05]	17 ⁷ /8 [454]	21 [533]	51 [23]	60 [27]	
3621M/4821S	³ /8 [9.53]	3/4 [19.05]	25 ⁷ /8 [657]	21 [533]	71 [32]	78 [35]	
3624M/4824S	3/8 [9.53]	3/4 [19.05]	257/8 [657]	241/2 [622]	83 [37]	93 [42]	
3624H/4824H/6024S/6024H	3/8 [9.53]	3/4 [19.05]	301/4 [768]	241/2 [622]	100 [45]	108 [48]	

^{*}The 14 inch, 2 ton RCF coil (2414) is part of the "N-Coil" design series, even though the coil shape resembles an "A" coil design.




Table 3: Coil Application

Coils can be matched to heating products as listed in table below.

Coil Model RCF	Furnace Width (In.) (mm)				
noi	Oil	Gas			
2414S 2417S 2417H/2417M 3617S	_	14 [356]			
2417S 2417M/2417H	171/2 [431]	171/2 [444]			
3617S		14 [356]			
2421M/2421H 3621S	21 [522]	21 [533]			
36215 3621M/4821S	21 [533]	171/2 [444]			
3624M/3624H 4824S/4824H	241/- [522]	241/2 [622]			
40245/4024F 6024S/6024H	241/2 [622]	21 [533]			

Accessories

• PLENUM ADAPTER ACCESSORY RXBA-AE

This plenum adapter accessory is for use with the 241/2" wide cased indoor cooling and heat pump coils. This allows a 241/2" wide cased coil to be installed on a 28" wide oil furnace. This is a field-installed accessory only.

• RXBA-AC (Upflow/Horizontal)

These plenum adapter accessories are for use when a cooling coil is matched with a gas furnace of one smaller size.


• HORIZONTAL ADAPTER KIT RXHH (See Figure 2)

This horizontal adapter kit is used to convert a upflow or downflow coil for a horizontal application. See Table 4 to order the proper horizontal adapter kit.

Table 4: Horizontal Adapter Kit Model No.

Coil Model	Horizontal Adapter Kit Model No.
24148	RXHH-A01
2417\$	RXHH-A02
2417M/2421M/3617S/ 3621S/2421H	RXHH-A03
3621M/3624M/ 4821S/4824S	RXHH-A04
3624H/4824H/ 6024S/6024H	RXHH-A05

FIGURE 2: HORIZONTAL ADAPTER KIT ILLUSTRATION



• INDOOR COIL CASING- RXBC (See Table 5)




Table 5: Unit Dimensions and Weights- RXBC Indoor Coil Casings

Model	Width	Height	Depth	Unit V	Veight	Supply Air/ Air Open	
Number	(in.) [mm]	(in.) [mm]	(in.) [mm]	Weight (lbs.) [Kg.]	Ship. Wt. (lbs.) [Kg.]	Width (in.) [mm]	Depth (in.) [mm]
RXBC-D14AI	14 [356]	233/16 [589]		19 [9]	23 [10]	13 [330]	
RXBC-D17AI	171/2 [445]	20 [508]	0.457	18 [8]	23 [10]	161/2 [419]	1001/
RXBC-D21AI	21 [533]	20 [508]	21 ⁵ / ₈ [549]	20 [9]	26 [12]	20 [508]	19 ³¹ / ₃₂
RXBC-D21BI	21 [533]	28 [711]	[0.0]	27 [12]	36 [17]	20 [508]	[000]
RXBC-D24AI	241/2 [622]	321/2 [826]		34 [16]	44 [20]	231/2 [597]	

Table 6: Uncased Coil Adapter Kit

Uncased Coil Adapter Model Number RXBA	A Width (in.) [mm]	Uncased Coil Model RCFP
B14x20	13 ¹ /8 [333]	-HUxx14
B17x20	16 ⁵ /8 [422]	-HUxx17
B21x20	201/8 [511]	-HUxx21
B24x20	235/8 [599]	-HUxx24

[] Designates Metric Conversions




Accessories (cont.)

• UNCASED COIL ADAPTER KIT RXBA- (See Figure 3 & 4)

This uncased coil adapter kit is used to adapt the coil to a furnace or ductwork. See Table 6 to order the proper adapter kit. Each kit contains a quantity of 20 adapters.

FIGURE 3: UNCASED COIL ADAPTER KIT ILLUSTRATION

FIGURE 4: UNCASED COIL ADAPTER KIT ASSEMBLED



Note: Sliding the coil into the coil rail before attaching coil rack front.

[] Designates Metric Conversions

GENERAL TERMS OF LIMITED WARRANTY*

Rheem will furnish a replacement for any part of this product which fails in normal use and service within the applicable periods stated, in accordance with the terms of the limited warranty.

*For complete details of the Limited and Conditional Warranties, including applicable terms and conditions, contact your local contractor or the Manufacturer for a copy of the product warranty certificate.

Parts.....Five (5) Years



In keeping with its policy of continuous progress and product improvement, Rheem reserves the right to make changes without notice.

