

MAINTENANCE AND CLEANING



WARNING

ELECTRICAL SHOCK HAZARD

Disconnect all power before servicing or cleaning. Failure to follow these instructions can result in death, electrical shock or fire.

MAINTENANCE

PLEASE DISCONNECT THE POWER CORD BEFORE CLEANING.

AIR FILTER

The air filter located on the left hand side of the unit can be removed simply by pulling the frame up.



CAUTION

Clean the air filter with a vacuum cleaner ensuring all dust is removed.


CONDENSER/EVAPORATOR

Use a brush attachment with a vacuum cleaner.

CASING

Wipe with a damp cloth and polish with a soft cloth.

To remove the air filter, please follow the arrow direction and pull the filter lightly, and then take out the filter for cleaning.



Safety Precautions



CAUTION

- Install in an accessible location.
- Only operate the unit in an upright position.
- Do not place in direct sunlight to avoid discoloration of the plastic.
- Do not use the unit on or in water to avoid electrical shock.
- Do not use near gas appliances, flammable liquids, or fires.

Power Sources



WARNING

- Make sure your electrical receptacle has the same configuration as your air conditioner's plug. If different, consult a Licensed Electrician.
- Do not use plug adapters.
Do not use an extension cord.
Do not remove ground prong.
- Always plug into a grounded 3 prong outlet. Failure to follow these instructions can result in death, fire, or electrical shock.

Other Warnings

- Do always keep the unit 3 feet away from TV sets or radios to avoid the risk of electromagnetic interference.
- Do always keep the air outlets free from obstructions.