



















<p>Record your model number.</p>	<p>Important Information Follow all local plumbing and building codes.</p>	<p>1 Determine the valve stem adapter length. Refer to the plaster guard.</p> 	<p>2 Hold a pencil against the wall and guard. Mark the edge of the guard on the pencil.</p> 	<p>3 Place the pencil inside the guard, aligning the mark with the edge of the guard.</p> 
<p>Thin Wall: Use the #3 adapter and the 1-3/8" (35 mm) screw.</p> 	<p>Standard Wall: Use the #1 adapter and the 1-3/4" (44 mm) screw.</p> 	<p>Thick Wall: Use the #2 adapter and the 2-3/8" (60 mm) screw.</p> 	<p>NOTE: If the guard is inside the finished wall, the valve needs to be moved forward.</p> 	<p>4 Remove the plaster guard. Place the spline adapter on the valve stem.</p> 
<p>5 Temporarily fit the valve stem adapter on the spline adapter.</p> 	<p>6 Position the handle on the valve stem adapter.</p> 	<p>7 Cold Position: Turn the handle clockwise. It should stop between 9 and 10 o'clock.</p> 	<p>8 Hot Position: Turn the handle counterclockwise. It should stop between 3 and 4 o'clock.</p> 	<p>9 To adjust position, remove the handle and valve stem adapter. Turn the spline adapter.</p> 
<p>10 Turn the handle to the 6 o'clock position. Remove the handle.</p> 	<p>11 Secure the valve stem adapter with the proper length screw. Thread the studs into the valve.</p> 	<p>12 Install the plate assembly and the nuts. The studs should not protrude beyond 7/16" (11 mm) Max.</p> 	<p>13 Place the escutcheon on the wall with the notch located downward in the 6 o'clock position.</p> 	<p>14 Point the handle down. Thread the bonnet to valve trim.</p> 

Questions? Problems? For additional assistance, please contact
KALLISTA's Customer Service Department at 1-888-4-KALLISTA
(1-888-452-5547) or kallista.com.