



Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions


Important Notes:

This vanity cabinet may be used freestanding, or may be mounted to a Wall (floating).

If you are using this cabinet as a freestanding unit, please refer to pages 05- 07.

If you are using this cabinet as a Wall mounted (floating) unit, please refer to pages 01 - 04 and 07.


*** For your safety and to achieve the best possible installation of this vanity cabinet, James Martin Vanities always recommends you consult with a professional contractor. Two people are required for the assembly and installation of this vanity cabinet.**



Step 1 Notes:

To prepare the cabinet for Wall mounting, you need to remove the attached wooden base.

Please place a blanket or other soft material on the floor and then place the cabinet on its back.



A = 4 pcs bolt 1/4" x 1 1/4"

B = 1 pc allen wrench #04

C = 4 pcs spring washer 1/4"

D = 4 pcs flat washer 1/4" x 5/8"



Step 2 Notes:

Please locate the red hardware bag which is included with the cabinet.

You will need the hex key (allen) wrench to remove the bolts and washers from the base.


Please keep the removed hardware and wrench for possible use in the future.




Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions


Materials for Installation:



Drill



Level



Tape
Measuring

Pencil



Stud Finder

F Pre-attached metal mounting (French Cleat) brackets



Step 3 Notes:

The metal mounting brackets have been pre-installed to the back of the cabinet 19 3/4" from the bottom of the cabinet, remove one piece from the back of the cabinet .

Step 4 Notes:

Draw a horizontal line on the Wall at your desired height. For this cabinet, most people use a height of 29 1/2"

Step 5 Notes:

Locate and mark the position of the Wall's interior studs to which you will fasten the metal bracket. We recommend the use of an electronic stud finder to locate the studs.

(Alternately, you may find studs by listening for a solid sound as you knock on the Wall)

Special Note 1:


If the studs in your bathroom do not line up to the mounting location for your vanity, additional wood blocking can be installed between the studs using standard 2 x 4 lumber.

Special Note 2:

Due to the narrow width of this cabinet, you may decide to use dryWall anchors if the Wall studs are not spaced appropriately.

IMPORTANT:


James Martin Vanities recommended you always consult with professional installers and contractors regarding the correct installation of our products.





Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions

**Materials
for
Installation:**


Drill



Pencil



Hammer


E=5PCS Drywall anchor Ø8*38**F**=1PC Metal Brackett 500mm**G**=5PCS Screws Ø4*40**Step 6 Notes:**

After you have located the Wall studs, position the metal bracket so the holes align with the center points of the studs. Mark these positions with a pencil.

Step 7 Notes:

Drill holes for the screws in the positions you have marked with the pencil.

Drill the holes' depth no less than 1 1/2", insert "E" to the holes by using hammer.







Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions

**Materials
for
Installation:**



Drill




Step 8 Notes:

Attach the metal bracket to the Wall using the screws "G" included in the red hardware bag.

Step 9 Notes:


Hang the cabinet on the metal bracket.





Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions

**Materials
for
Installation:**


Drill



Pencil

* For your safety and to achieve the best possible installation of this vanity cabinet, James Martin Vanities always recommends you consult with a professional contractor. Two people are required for the assembly and installation of this vanity cabinet.


Warning: To prevent accidental tip-over of these cabinets, you must follow these steps.

**Step 1a Notes:**

Remove the pre-attached metal mounting (French Cleat) brackets

Step 2a Notes:

Put the cabinet against the wall, mark the positions with a pencil through the pre-drilled holes on the back rail.






Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW

Assembly / Installation Instructions

Materials for Installation:



Drill




Hammer

E=5PCS Drywall anchor Ø8*38

H=3PCS Screws Ø4*60

I=3pcs Flat Washer 1/4" x 1/2"




Step 3a Notes:

Drill holes for the screws in the positions you have marked with the pencil.

Drill the holes' depth no less than 1 1/2", insert hardware **E** (drywall anchors) to the holes by using hammer if wall studs are not in the correct positions.

Step 4a Notes:



Secure the cabinet to the wall using Screw **H** and Flat Washer **I** for wall studs.





Addison Vanity Cabinets: E445-V24-MCA E445-V24-GW
Assembly / Installation Instructions

**Materials
for
Installation:**



Step 5a Notes:

Properly align and secure the countertop to the cabinet with high quality adhesive.